


# INSTALLATION AND OPERATING INSTRUCTIONS

→ BIOCLASS NG (FOR EXTERNAL USE)



Thank you for choosing a DOMUSA heating boiler. Within the product range offered by **DOMUSA** you have chosen **BioClass NG** model. With a suitable hydraulic installation and with a correct fuel, this boiler will provide the ideal level of comfort for your home.

This manual forms an essential part of the product and it must be given to the user. We recommend you read the warnings and recommendations in the manual carefully, as they contain important information on the safety, use and maintenance of the installation.

These boilers must be installed by qualified personnel only, in accordance with the legislation in force and following the manufacturer's instructions.

Commissioning of these boilers and any maintenance operations must only be carried out by **DOMUSA's** Authorised Technical Assistance Services.

Incorrect installation of these boilers could result in damage to people, animals or property, and the manufacturer will hold no liability in such cases.

**DOMUSA** informs all parties concerned that, in compliance with section 1 of the first additional provision of Law 11/1997, the responsibility for delivering packaging waste or used packaging for its proper environmental management will be that of the final owner of the product (Article 18.1 Royal Decree 782/1998). At the end of its useful life, the product must be taken to a selected collection point for electrical and electronic equipment or must be returned to the distributor at the time of purchasing a new equivalent appliance. For more detailed information on the collection schemes available, contact either the collection facilities of the local authority or the distributor where the purchase was made.


## INDEX

	<b>Page</b>
1 LIST OF COMPONENTS .....	3
2 CONTROL COMPONENTS .....	4
3 INSTALLATION INSTRUCTIONS .....	5
3.1 LOCATION .....	5
3.2 HYDRAULIC INSTALLATION .....	5
3.3 INSTALLING A SANIT HOT WATER TANK (OPTIONAL) .....	6
3.4 FUEL .....	6
3.5 INSTALLING THE HOPPER .....	7
3.6 ELECTRICAL CONNECTION .....	8
3.7 CHIMNEY INSTALLATION .....	9
3.8 BIO HYDRAULIC KIT INSTALLATION .....	9
3.9 INSTALLATION WITH A BT BUFFER TANK (OPTIONAL) .....	10
3.10 INSTALLATION WITH A BT-DUO BUFFER TANK (OPTIONAL) .....	14
4 COMMISSIONING OF THE BOILER .....	16
4.1 PRIOR WARNINGS .....	16
4.2 ELECTRICAL CONNECTION .....	16
4.3 FILLING THE INSTALLATION WITH WATER .....	16
4.4 INITIAL CALIBRATION OF THE FEED AUGER .....	16
4.5 COMMISSIONING .....	17
4.6 INSTALLATION DELIVERY .....	17
5 DIGITAL DISPLAY .....	18
6 OPERATION .....	21
6.1 "ONLY HEATING" OPERATION .....	21
6.2 OPERATING WITH A SANIT DHW STORAGE TANK (OPTION) .....	21
6.3 BOILER TEMPERATURE SET POINT SELECTION .....	22
6.4 DHW TEMPERATURE SET POINT SELECTION (WITH DHW TANK INSTALLED ONLY) .....	22
6.5 SELECTING THE SETPOINT TEMPERATURE OF THE BUFFER TANK (ONLY WITH BUFFER TANK) .....	23
6.6 FUEL LEVEL DETECTION SYSTEM OPERATION .....	23
6.7 FUNCTIONING ACCORDING TO OUTDOOR TEMPERATURE CONDITIONS OTC (OPTION) .....	24
7 OPERATING WITH BIO HYDRAULIC KITS (OPTIONAL) .....	25
8 OPERATION WITH A BT BUFFER TANK (OPTIONAL) .....	26
8.1 OPERATION WITH A TEMPERATURE SENSOR IN THE BT BUFFER TANK (P.08 = 1 OR 2) .....	26
8.2 OPERATION WITH A CONTROL THERMOSTAT IN THE BT BUFFER TANK (P.08 = 3 OR 4) .....	27
9 OPERATION WITH A BT-DUO BUFFER TANK (OPTIONAL) .....	28
10 OPERATING WITH LAGO FB OT+ REMOTE CONTROLLER (OPTIONAL) .....	29
11 USER MENU .....	30
11.1 ASHTRAY STATUS .....	31
12 SETUP MENU .....	32
12.1 TIMERS PROGRAMMING PROCESS .....	33
12.2 BOILER TIMER PROGRAMMING .....	33
12.3 DHW RECIRCULATION FUNCTION TIMER PROGRAMMING (DHW TANK OPTION ONLY) .....	33
12.4 TIME SETTING .....	34
12.5 ASHTRAY EMPTY WARNING FUNCTION .....	35
12.6 MANUAL SETTING OF FEED AUGER CALIBRATION .....	35
12.7 SCREEN CONTRAST SETTING .....	35
13 CALIBRATION MENU .....	36
13.1 FEED AUGER FILLING .....	37
13.2 FEED AUGER CALIBRATION .....	38
13.3 MANUAL SETTING OF FEED AUGER CALIBRATION .....	39
13.4 MANUAL ASH CLEANING ACTIVATION .....	39
13.5 MANUAL CIRCULATION PUMPS ACTIVATION .....	39
14 TECHNICAL MENU .....	39
14.1 ENTRY AND SET THE ACCESS CODE ("COD", P.25) .....	42
15 BOILER'S SETUP PARAMETERS .....	43
15.1 BOILER MODEL (P.01) .....	43
15.2 BOILER HEAT OUTPUT (P.02, P.03) .....	43
15.3 GENERAL FAN SPEED FACTOR (P.04) .....	43
15.4 FUEL FOR IGNITION (P.05) .....	43

# BioClass NG (For external use)

15.5 FUEL CONSUMPTION (P.06) .....	43
15.6 FUEL TYPE (P.07).....	43
15.7 MANAGING BT AND BT-DUO BUFFER TANKS (P.08, P.28).....	44
15.8 AUXILIARY PARAMETER FOR FUEL SELECTION (P.26) .....	44
15.9 BOILER MINIMUM TEMPERATURE MODE (P.13, P.14) .....	44
16 HEATING CIRCUIT'S SETUP PARAMETERS.....	44
16.1 HEATING PUMP POST-CIRCULATION TIME (P.15) .....	44
16.2 BOILER'S PUMP OPERATING MODE (P.18) .....	45
16.3 MINIMUM BOILER WATER PRESSURE (P.19) .....	45
16.4 MAXIMUM HEATING FLOW TEMPERATURE OF MIXED CIRCUITS (P.27) .....	45
17 DHW CIRCUIT'S SETUP PARAMETERS .....	45
17.1 DHW INSTALLATION MODE (P.09).....	45
17.2 DHW PUMP POST-CIRCULATION TIME (P.16).....	45
17.3 LEGIONELLA PROTECTION FUNCTION (P.17).....	46
17.4 DHW RE-CIRCULATION FUNCTION (P.20 = 2) .....	46
18 ADDITIONAL FUNCTIONS .....	46
18.1 RESET DEFAULT VALUES (P.24) .....	46
18.2 PUMPS ANTI-LOCK FUNCTION.....	46
18.3 ANTI-FROST FUNCTION.....	46
18.4 BOILER PRESSURE SENSOR FUNCTION .....	46
18.5 CONNECTING THE LAGO FB OT+ REMOTE CONTROL.....	47
18.6 ROOM THERMOSTAT CONNECTION .....	47
19 MULTI-FUNCTIONAL RELAY (P.20).....	47
19.1 BOILER ALARMS EXTERNAL SIGNAL (P.20 = 1) .....	47
19.2 DHW RE-CIRCULATION FUNCTION (P.20 = 2) .....	47
19.3 AUTOMATIC WATER FILLING FUNCTION (P.20 = 3).....	48
20 CLEANING THE ASH DRAWER.....	49
20.1 SAFETY WARNINGS: .....	49
21 SAFETY LOCK-OUTS .....	50
21.1 WATER OVERHEAT SAFETY LOCK-OUT (E-11) .....	50
21.2 FUEL ENTRANCE TUBE OVERHEAT SAFETY CUT-OUT (E-05) .....	50
21.3 LOW PRESSURE LOCK-OUT .....	51
22 SHUTTING DOWN THE BOILER.....	51
23 EMPTYING THE BOILER .....	51
24 BOILER MAINTENANCE .....	51
24.1 FREQUENCY OF MAINTENANCE OF THE BOILER AND CHIMNEY .....	51
24.2 BURNER CLEANING PROCEDURE .....	52
24.3 HEAT EXCHANGER CLEANING PROCEDURE .....	53
24.4 DRAINING THE CONDENSATE WATER .....	54
24.5 BOILER WATER CHARACTERISTICS.....	54
25 CHIMNEY SUPPORT .....	54
26 DIAGRAMS AND MEASUREMENTS.....	55
27 ELECTRICAL CONNECTION DIAGRAM .....	57
27.1 BOILER .....	57
27.2 BURNER.....	58
27.3 HOPPER .....	59
28 ELECTRICAL DIAGRAM.....	60
29 TECHNICAL DATA .....	61
30 CIRCULATION PUMP AND PRESSURE DROP .....	62
30.1 HIGH EFFICIENCY CIRCULATION PUMP .....	62
30.2 BOILER PRESSURE DROP .....	63
30.3 CIRCULATING PUMP OPERATING STATUS.....	63
31 SPARE PARTS LIST .....	64
32 ALARM CODES .....	73
33 GUARANTEE CONDITIONS.....	76


## 1 LIST OF COMPONENTS



- |                                    |                                     |
|------------------------------------|-------------------------------------|
| 1. Feed auger.                     | 8. Fuel entrance safety thermostat. |
| 2. Sensor housing.                 | 9. Heat exchanger.                  |
| 3. Automatic Air vent.             | 10. Ash drawer.                     |
| 4. Flue outlet                     | 11. Burner.                         |
| 5. Fan.                            | 12. Air pressure sensor.            |
| 6. Heat exchanger cleaning system. | 13. Peephole.                       |
| 7. Water pressure sensor.          |                                     |

# BioClass NG (For external use)

## 2 CONTROL COMPONENTS



### 14. MENU touch button:

This button is used to access and browse through the "User Menu".

### 15. Digital display:

It is the main boiler functioning display, on which all the operating information, settings and values appear. This display is also used to access the appliance's user and service settings. In standard operating mode (default display), the actual boiler temperature is shown. If malfunction occurs, an alarm code will appear on the digital display instead of the temperature.

### 16. RESET touch button:

This button is used to restore functioning of the boiler after a lock-out situation. Also it is used to exit from any of the menus or parameters of the boiler without saving it and to return to the previous menu level.

### 17. ON touch button:

This button switches on and off the boiler.

### 18. Boiler temperature touch button:

This button is used to select the boiler set point temperature. It is also used to disable the hot water function.

### 19. DHW temperature touch button:

This button is used to select the desired domestic hot water set point temperature (only if a DHW tank is connected to the boiler). It is also used to disable the DHW function.

### 20. SET touch button:

This button is used to access and browse through the "Setup menu". Touch this button to access the settings options.

## 3 INSTALLATION INSTRUCTIONS

The boiler must be installed by personnel authorised by the Ministry of Industry, in compliance with the applicable laws and regulations.

This boiler is suitable for heating water to a temperature below boiling point at atmospheric pressure. It must be connected to a heating installation and/or a domestic hot water distribution network, which must always be compatible with its performance and power.

This appliance must only be used for the purpose for which it has been expressly designed. Any other use is considered unsuitable and therefore hazardous. The manufacturer shall not be considered liable under any circumstances for damage caused by unsuitable, erroneous or irrational use.

Remove all the packaging and check the contents are complete. In case of doubt, do not use the boiler. Contact your supplier. Keep the packaging elements out of reach of children, as they can be dangerous.

When you no longer wish to use the boiler, disable the parts that could be a potential source of hazard.

### 3.1 Location

The boiler unit should be positioned so that the air inlets located on the upper rear part, lower part of the door and below the base are not obstructed. Enough space must be left for maintenance operation even when it is placed between furniture. One metre of free distance must be left above and around the boiler for this purpose.

### 3.2 Hydraulic installation

The hydraulic installation must be made by qualified personnel. The applicable installation legislation is to be complied with, and the following recommendations should also be taken into account:

- The inside of the installation piping should be thoroughly cleaned before switching on the boiler.
- We recommend inserting cut-off valves between the installation piping and the boiler to simplify maintenance tasks.
- Leave a free space around the boiler for carrying out any maintenance and repair operations.
- Drain valves and suitable devices for correctly bleeding the air from the circuit during the boiler filling stage should be fitted.
- Install all the necessary safety elements (expansion vessel, safety valve, etc.) to comply with the applicable regulations for the installation.
- If the boiler is installed at a lower height than the heating installation, it is recommendable to create a siphon at the boiler outlet, to prevent the installation from heating up due to natural convection when heating is not required.
- The boiler is supplied with a 12 litre closed expansion vessel installed. Depending on the total volume of the hydraulic circuit, it may be necessary to install an additional expansion vessel consistent with this volume.
- The boiler and the pellet hopper must be assembled on a compact and sufficiently robust base which can bear the weight of the assembly when it is fully loaded. It is recommended a concrete base of at least 70 mm of width.

**IMPORTANT:** In order to avoid damages to the boiler, it is necessary to add antifreeze to the water heating circuit. For long periods of shutdown of the boiler, it is recommended to drain all water from it.


# BioClass NG (For external use)

## 3.3 Installing a Sanit hot water tank (Optional)

For a correct electrical connection of a Sanit DHW hot water tank with **BioClass NG** boiler, these steps should be followed:

- **Unplug the boiler from the mains power.**
- Connect a DHW temperature sensor (supplied optionally) to the sensor terminal strip **J7 (Sa; terminals 16 and 17)** (see "*Connections Diagram*").
- Insert the temperature sensor bulb in the bulb-holder sheath provided on the hot water tank.
- Connect the 3-way DHW diverter valve or the hot water tank booster pump (depending on the installation, modify parameter **P.09**) to the supply terminal strip **J3 (BA; terminals 6 and N)** (see "*Connections Diagram*").

The hydraulic installation for the 3-way DHW diverter valve should be made so that the heating circuit can flow through the valve when it is in rest position (not energised):



For correct hydraulic installation of the hot water tank, carefully follow the assembly and connection instructions enclosed with the same.

## 3.4 Fuel


**BioClass NG** boiler must be fuelled by **DIN PLUS** certified wood pellet. The **DIN PLUS** certificate assures that the fuel's humidity levels and calorific value are ideal for optimum boiler functioning. If this requirement is not complied with, **DOMUSA's** guarantee of the appliance will automatically be null and void.

The following points should be taken into account for correct fuel storage:

- The stored pellets should be kept dry all year round.
- The applicable legislation in each country for correct fuel storage must be complied with.

### 3.5 Installing the hopper

DOMUSA supplies a hopper for storing the pellets with the boiler.




**IMPORTANT:** Ensure the height of the elliptical holes on the sides of the boiler and on the hopper coincide, for correct insertion of the feed auger. To do this, make the necessary adjustments for height and depth (correctly positioning the hopper).

## BioClass NG (For external use)

In order to prevent the hopper from running out of pellets, **BioClass NG** boiler integrates a fuel level detection system. This system includes a level sensor assembled into the hopper that is compulsory to connect in the boiler's terminals strip, located in the bottom side of the main board.

The sensor (**Dp**) is supplied with a 3 way terminal strip (**J10**; terminals no. **7**, **8** and **9**) to connect it within the boiler's electronic board (see section "*Electrical Connection Diagram*"), as it is shown in the following Figure:



In addition, the fuel level detection system includes 2 terminal strips (**J8** and **J9**) to connect warning devices in order to warn when a low level of fuel is detected and the functioning of the boiler is blocked. The terminal strip **J8** generates a 230 V~ signal between terminals **N - 3** or **N - 4** when a low level of pellets is detected. The terminal strip **J9** closes a voltage free contact between terminals **5** and **6**, generating a short circuit signal between them when a low level of pellets is detected.

In section "Fuel level detection system operation" is shown a detailed description of the way of functioning of each component of this system.

### 3.6 Electrical Connection

The boiler is equipped for connection at 230 V~, 50 Hz to terminals no. **1** and **2** of terminal strip **J1** (see "*Electrical Connection Diagram*"). **Remember to earth the appliance.**

The boiler has a terminal strip **TA<sub>1</sub>** (**J6**) prepared for connecting a room thermostat or room chronothermostat (see "*Electrical Connection Diagram*") for remote ON/OFF operation of the heating circuit. To connect the room thermostat, remove the bridge joining the terminals on the strip **TA<sub>1</sub>**. Also, it is the terminal strip **J5** for connecting a remote controller Lago FB OT+ for a complete remote control of heating and DHW circuits (see "*Operating with LAGO FB OT+*").

The terminal strip **J2** includes terminals for connecting the feed auger, whereas the terminal strip **J3** includes terminals for connecting the circulation pump of the boiler (**BC**) and the 3-way diverter valve (or circulation pump) for the optional DHW circuit. The terminal strip **J7** includes terminals for connecting a sensor for the optional DHW circuit. This sensor must be supplied by **DOMUSA**.

**IMPORTANT:** Before carrying out any work on the boiler's electrical installation, always ensure it is disconnected from the mains.

### 3.7 Chimney installation

**BioClass NG** boiler is a biomass boiler and it is essential for it to be connected to a flue, i.e. a smoke duct able to create a pressure drop (which in this case should be between 0.10 and 0.20 mbar) and must comply with the regulations in force.

The functioning of the boiler is very sensitive to the size and position of the chimney. For this reason, the chimney must be installed by qualified personnel.


To create a pressure drop, the following recommendations should be taken into account:

- It must have suitable insulation and protrude a metre above the top of the roof line in case the boiler is near a building and, in all cases, it must comply with the requirements of the current related standards, legislation and regulations.
- It should be vertical, avoiding any angles greater than 45°. It should always have the same shape. It is recommendable for it to be circular, and never smaller than the boiler outlet.
- **It is compulsory to install a fume inspection plate with condensation collection, to remove the condensation generated in the flue.** Otherwise, the condensation may reach the inside of the boiler and cause irreparable damage, **which would not be covered by DOMUSA's guarantee. The condensation pipe should lead to a drain outlet**, as a large amount of water may be generated. This connection must be made in compliance with the regulations for draining off condensation water to the drain network.

### 3.8 BIO hydraulic kit installation

In option a **BIO hydraulic kit**, within the kits range offered by **DOMUSA**, could be connected to **BioClass NG** boiler. In that way the features of the boiler will be increased. Look at the following instructions for a correct installation:

- **Unplug the boiler and the hydraulic kit from the main power supply.**
- Connect the communication between the boiler and BIO hydraulic kit. Use the cable of two wires with two connectors (+A –B) supplied with the kit (documentation bag). **To assure the correct running of BIO hydraulic Kit it is essential to respect the polarity of the connection. The same wire must be connected to the +A terminal of the boiler as well as to the +A terminal of the hydraulic Kit. Same operation with the –B terminals as it is shown in the Figure below.**
- After connecting the communication between the boiler and the hydraulic Kit, plug the **BIO hydraulic Kit** to the main power supply. It is recommended to plug the Kit before the boiler to assure a correct running of the system.
- Plug the boiler to the main power supply.
- Follow the instructions provided with the kit to assure a correct installation.



**NOTE:** It is recommended to plug the kit before the boiler to assure a correct running.

## BioClass NG (For external use)

**IMPORTANT:** For the correct operation of the hydraulic kit BIO is essential to respect the polarity of the 2-wires of the communication connection

### 3.9 Installation with a BT Buffer Tank (Optional)

The **BioClass NG** boiler can be accompanied by a **BT Buffer Tank** during the installation from the wide range offered by DOMUSA, which may increase the benefits provided by the boiler in the heating service.


For this reason, the electronic control of the boiler is equipped with an input for a temperature sensor or a temperature thermostat (**Sbt**; terminals 18-19 on connection strip **J7**) and a circulation pump output (**Bbt**; terminals N-7 on the connection strip **J2**) dedicated exclusively to managing the heating of the buffer tank. Using these control elements of the boiler you will be able to manage 4 different modes of buffer tank hydraulic installation. The installation type will be selected using parameter **P.08** in the "Technician" menu on the control panel.

The boiler is supplied with this installation option disabled. To enable it, the electrical resistance (**Rbt**) connected between terminals **18** and **19** of connection strip **J7** (see "Connection Diagram") must be disconnected and replaced with a temperature sensor (supplied as an option by DOMUSA) or a control thermostat installed in the BT buffer tank. After disconnecting the resistance in the "Technician" menu of the control panel, parameter **P.08** must be enabled, via which you can select the installation mode desired.

The following sections describe in detail the hydraulic and electrical connection characteristics for each installation mode.

#### 3.9.1 Installation with Sanit DHW tank after BT tank and control by temperature sensor (P.08 = 1)

In this installation mode, all heating circuits, as well as the circuit for producing DHW by accumulation, if present, must be hydraulically connected to the BT buffer tank. In other words, as shown in the following hydraulic diagram, the BT buffer tank is connected to the boiler, interposing a circulation pump (**Bbt**), and all the heating circuits of the system are connected to the BT tank. The temperature of the BT tank is controlled and managed by a temperature sensor (**Sbt**) immersed in the buffer tank and electrically connected to the boiler. The temperature sensor is optionally supplied by DOMUSA.



After the hydraulic installation of all the system components, proceed as follows to carry out the correct electrical connection of the BT buffer tank to the **BioClass NG** boiler:


- **Unplug the boiler from the mains power.**
- Disconnect the electrical resistance (**Rbt**) connected between terminals **18** and **19** of connection strip **J7** (see "Connection Diagram").
- Connect the BT tank temperature sensor (supplied optionally) to the sensor connection strip **J7** (**Sbt**; terminals **18** and **19**) (see "Connection Diagram").

- Insert the temperature sensor bulb in the bulb-holder sheath provided in the buffer tank.
- Connect the BT tank feed pump to the component connection strip **J2 (Bbt; terminals N and 7)** (see "Connection Diagram").
- Connect the boiler to the mains power.
- Using the control panel, access parameter **P.08** in the "Technician" menu (see "Technician Menu") and set the value to "1".
- After that, set also the parameter **P.28** "BT buffer tank temperature hysteresis", if it is necessary.

Once the hydraulic and electrical connection described above has been completed, to adjust and configure the BT buffer tank operation, carefully read the section "Operation with a BT buffer tank" in this manual.

### 3.9.2 Installation with Sanit DHW tank before BT tank and control by temperature sensor (P.08 = 2)

In this installation mode, all heating circuits must be hydraulically connected to the BT buffer tank, and the circuit for producing DHW by accumulation should be hydraulically connected to the boiler, upstream from the BT buffer tank. In other words, the BT buffer tank and the Sanit DHW tank, if present, are connected in parallel to the boiler. Depending on the type of installation of the DHW tank (installation with DHW diverter valve or with a DHW pump), the BT tank feed pump (**Bbt**) will be installed as indicated in the following hydraulic diagrams. The temperature of the BT tank is controlled and managed by a temperature sensor (**Sbt**) immersed in the buffer tank and electrically connected to the boiler. The temperature sensor is optionally supplied by DOMUSA.



After the hydraulic installation of all the system components, proceed as follows to carry out the correct electrical connection of the BT buffer tank to the **BioClass NG** boiler:

- **Unplug the boiler from the mains power.**
- Disconnect the electrical resistance (**Rbt**) connected between terminals **18** and **19** of connection strip **J7** (see "Connection Diagram").

## BioClass NG (For external use)


- Connect the BT tank temperature sensor (supplied optionally) to the sensor connection strip **J7 (Sbt)**; terminals **18** and **19** (see "Connection Diagram").
- Insert the temperature sensor bulb in the bulb-holder sheath provided in the buffer tank.
- Connect the BT tank feed pump to the component connection strip **J2 (Bbt)**; terminals **N** and **7** (see "Connection Diagram").
- Connect the boiler to the mains power.
- Using the control panel, access parameter **P.08** in the "Technician" menu (see "Technician Menu") and set the value to "**2**".
- After that, set also the parameter **P.28** "BT buffer tank temperature hysteresis", if it is necessary.

For the correct hydraulic and electrical installation of a Sanit DHW tank with a **BioClass NG** boiler, carefully follow the directions in the section "Installing a Sanit tank" in this manual.

Once the hydraulic and electrical connection described above has been completed, to adjust and configure the BT buffer tank operation, carefully read the section "Operation with a BT buffer tank" in this manual.

### 3.9.3 Installation with Sanit DHW tank after BT tank and control by thermostat (P.08 = 3)

In this installation mode, all heating circuits, as well as the circuit for producing DHW by accumulation, if present, must be hydraulically connected to the BT buffer tank. In other words, as shown in the following hydraulic diagram, the BT buffer tank is connected to the boiler, interposing a circulation pump (**Bbt**), and all the heating circuits of the system are connected to the BT tank. The temperature of the BT tank is controlled and managed by a thermostat (**Tbt**) installed and immersed in the buffer tank and electrically connected to the boiler. The temperature control thermostat is not supplied by DOMUSA but can be purchased at any specialist central heating supplies warehouse.




After the hydraulic installation of all the system components, proceed as follows to carry out the correct electrical connection of the BT buffer tank to the **BioClass NG** boiler:

- **Unplug the boiler from the mains power.**
- Disconnect the electrical resistance (**Rbt**) connected between terminals **18** and **19** of connection strip **J7** (see "Connection Diagram").
- Connect the **NC** contact (normally closed) on the BT tank control thermostat on the sensor connection strip **J7 (Sbt)**; terminals **18** and **19** (see "Connection Diagram").
- Insert the thermostat bulb into the bulb-holder sheath provided in the buffer tank.
- Connect the BT tank feed pump to the component connection strip **J2 (Bbt)**; terminals **N** and **7** (see "Connection Diagram").
- Connect the boiler to the mains power.
- Using the control panel, access parameter **P.08** in the "Technician" menu (see "Technician Menu") and set the value to "**3**".

Once the hydraulic and electrical connection described above has been completed, to adjust and configure the BT buffer tank operation, carefully read the section *“Operation with a BT buffer tank”* in this manual.

### 3.9.4 Installation with Sanit DHW tank before BT tank and control by thermostat (P.08 = 4)

In this installation mode, all heating circuits must be hydraulically connected to the BT buffer tank, and the circuit for producing DHW by accumulation should be hydraulically connected to the boiler, upstream from the BT buffer tank. In other words, the BT buffer tank and the Sanit DHW tank, if present, are connected in parallel to the boiler. Depending on the type of installation of the DHW tank (installation with DHW diverter valve or with a DHW feed pump), the BT tank feed pump (**Bbt**) will be installed as indicated in the following hydraulic diagrams. The temperature of the BT tank is controlled and managed by a thermostat (**Tbt**) installed and immersed in the buffer tank and electrically connected to the boiler. The temperature control thermostat is not supplied by DOMUSA but can be purchased at any specialist central heating supplies warehouse.



After the hydraulic installation of all the system components, proceed as follows to carry out the correct electrical connection of the BT buffer tank to the **BioClass NG** boiler:

- **Unplug the boiler from the mains power.**
- Disconnect the electrical resistance (**Rbt**) connected between terminals **18** and **19** of connection strip **J7** (see *“Connection Diagram”*).
- Connect the **NC** contact (normally closed) on the BT tank control thermostat on the sensor connection strip **J7** (**Sbt**; terminals **18** and **19**) (see *“Connection Diagram”*).
- Insert the thermostat bulb into the bulb-holder sheath provided in the buffer tank.
- Connect the BT tank feed pump to the component connection strip **J2** (**Bbt**; terminals **N** and **7**) (see *“Connection Diagram”*).
- Connect the boiler to the mains power.
- Using the control panel, access parameter **P.08** in the *“Technician”* menu (see *“Technician Menu”*) and set the value to **“4”**.

For the correct hydraulic and electrical installation of a Sanit DHW tank with a **BioClass NG** boiler,

## BioClass NG (For external use)

carefully follow the directions in the section *"Installing a Sanit tank"* in this manual.

Once the hydraulic and electrical connection described above has been completed, to adjust and configure the BT buffer tank operation, carefully read the section *"Operation with a BT buffer tank"* in this manual.


### 3.10 Installation with a BT-DUO buffer tank (Optional)

The **BioClass NG** boiler can be accompanied by a **BT-DUO Buffer Tank** during the installation from the wide range offered by DOMUSA, which may increase the benefits provided by the boiler in the heating service. This tank has a hot water storage tank inside, thereby adding the provision of DHW in addition to the buffer tank functionality. For this reason, its connection to the boiler as well as its operating configuration are specific.

For this reason the electronic control of the boiler is equipped with an input for connecting the primary control thermostat **Tcp** of the BT-DUO tank (input **Sbt**; terminals 18-19 on connection strip **J7**) and a circulation pump output (**Bbt**; terminals N-7 on the connection strip **J2**) dedicated exclusively to managing the heating of the buffer tank. Also, for correctly managing the DHW production in the tank integrated in the BT-DUO tank, a DHW temperature sensor (supplied optionally) must be included in the installation.

The boiler is supplied with this installation option disabled. To enable it, the electrical resistance (**Rbt**) connected between terminals **18** and **19** of connection strip **J7** (see *"Connection Diagram"*) must be disconnected and replaced with a temperature sensor (supplied as an option by DOMUSA) or a control thermostat installed in the BT buffer tank. After disconnecting the resistance in the "Technician" menu of the control panel, parameter **P.08** must be enabled, via which you can select the installation mode and appropriate functioning for this type of buffer tank.

The BT-DUO buffer tank is hydraulically connected to the boiler, interposing a circulation pump (**Bbt**), and all the central heating circuits of the system are connected to the BT-DUO tank. For the correct hydraulic installation of the **BT-DUO** tank and the feed pump **Bbt**, carefully follow the instructions in the following hydraulic diagram:



After the hydraulic installation of all the system components, proceed as follows to carry out the correct electrical connection of the BT-DUO buffer tank to the **BioClass NG** boiler:

- **Unplug the boiler from the mains power.**
- Disconnect the electrical resistance (**Rbt**) connected between terminals **18** and **19** of connection strip **J7** (see *"Connection Diagram"*).
- Using a 2-wire electrical hose connect the **TAcald** terminals (terminals **7** and **8** in the wiring diagram of the BT-DUO tank manual) of the BT-DUO tank control thermostat (**Tcp**) to the sensor connection strip **J7** (**Sbt**; terminals **18** and **19**) (see *"Connection Diagram"*).

- Connect the DHW temperature sensor (supplied optionally) to the sensor connection strip **J7 (Sa; terminals 16 and 17)** (see "*Connection Diagram*"), previously removing the resistance **Ra**, supplied as standard with the boiler.
- Insert the DHW temperature sensor bulb into the bulb-holder sheath provided in the DHW tank of the BT-DUO buffer tank.
- Connect the BT-DUO tank feed pump to the component connection strip **J2 (Bbt; terminals N and 7)** (see "*Connection Diagram*").
- Connect the boiler to the mains power.
- To correctly configure the type of installation you must adjust parameters **P.08** y **P.09** in the "Technician" menu on the control panel. Access parameter **P.08** in the "Technician" menu (see "*Technician Menu*") and set the value to "**4**". Next, access parameter **P.09** from the same menu and set the value to "**0**".

For the correct hydraulic and electrical installation of a **BT-DUO** buffer tank, carefully follow the instructions in the manual supplied with it.

Once the hydraulic and electrical connection described above has been completed, to adjust and configure the BT-DUO buffer tank operation, carefully read the section "*Operation with a BT-DUO buffer tank*" in this manual.

# BioClass NG (For external use)

## 4 COMMISSIONING OF THE BOILER

### 4.1 Prior warnings

Repair and maintenance of the boiler must be carried out by a qualified professional, authorised by **DOMUSA**. For optimum functioning and conservation of the boiler, it should be serviced annually.

Periodically check and clean the flue gases ducts.

Always keep the cover of the fuel hopper closed.

Use only the fuel recommended by Domusa (ENplus-A1) within this boiler.

Keep the boiler air inlets clean and free of obstacles. These inlets are located on the upper rear part, lower part of the door and below the base. They are necessary for the combustion and refrigeration of the boiler and in the event of snow or any other element obstructing them, they must be cleaned as soon as possible.

Carefully read this instruction manual and keep it in a safe, easily-accessible place. **DOMUSA** will not be liable for any damages caused by failure to follow these instructions.

Before any servicing, **disconnect the boiler from the mains power supply**.

### 4.2 Electrical Connection

It is recommended that a bipolar switch be installed close to the boiler in order to interrupt the mains supply to the boiler during maintenance.

### 4.3 Filling the installation with water

The hydraulic installation must include a fill valve, drain valves and the necessary hydraulic components for correctly filling the installation.

To fill the installation, open the fill valve until the parameter *"Water pressure"* of *"User Menu"* shows a pressure of 1 - 1.5 bars. The installation must be filled slowly, bleeding the air from the water circuit using the drain valves provided on the same. Close the fill valve after filling.

**BioClass NG** boilers have a pressure sensor for controlling the pressure of the installation. If the installation does not have the minimum pressure set at **P.19** parameter of *"Technical Menu"* (by default 0.5 bar), a low pressure alarm will appear ("**E-19**").

**IMPORTANT: Switching on the boiler with no water inside could result in serious damage.**

### 4.4 Initial calibration of the feed auger

**BioClass NG** boiler is equipped with a feed auger to supply the fuel. Follow the instructions described in *"Installing the hopper"* section to install it correctly. Due to diversity of feed augers and the range of different hoppers, it is needed to calibrate the feed auger minimum twice to assure the correct running.

During the commissioning, after filling the installation, ("**E-25**") alarm code is displayed. It isn't possible to switch on the boiler before calibrating the feed auger. Follow the instructions described in *"Feed auger calibration"* section of *"Setup menu"* to assure a correct calibration. Once the calibration is finished, ("**E-25**") alarm would disappear and it will be possible to switch on the boiler.

## 4.5 Commissioning

In order for the **guarantee to be valid**, the boiler must be commissioned by **personnel authorised by DOMUSA**. Before beginning the commissioning, the following must be complied with:

- The boiler must be plugged in to the mains power supply.
- The installation must be filled with water (the pressure must be between 1 and 1.5 bar).
- The hopper must be filled with fuel.

The commissioning sequence is as follows:

- Check the flue is correctly installed using a condensation inspection tap and a draught stabiliser.
- Check the hopper and the feed auger are correctly installed. **The feed auger must be calibrated for a correct boiler functioning** (See *"Calibrating the feed auger"*). Check the right type of fuel is being used (wood pellet must be **DIN PLUS**).
- If the installation has flow and return valves, check they are open.

## 4.6 Installation delivery


After commissioning, the Technical Assistance Service will explain to the user how the boiler functions, making any observations they consider relevant.

The installer is responsible for clearly explaining to the user the functioning of any control or regulation device forming part of the installation but not supplied with the boiler.

# BioClass NG (For external use)

## 5 DIGITAL DISPLAY

BioClass NG boiler is equipped with a digital touch display for viewing and adjustment of the different boiler settings. The display has various display areas where different icons and numbers appear to indicate the different status of the boiler.



**A** Boiler status: Heating function enabled.  
 DHW production enabled.

**B** Icon for flame detection: Flame detected.

**C** Timer icons:

It is displayed when the real time is inside "ON" programmed period.

It is displayed when actual time is inside "OFF" programmed period.

When any screen is displayed it relates to the display of actual time, programming, etc.

**D** Scale marking bar: The meaning can change depending on the parameter displayed:

**Time scale:** Used to indicate values or settings related to the time and/or time programming:



**Lux scale:** Used to indicate the lux level read by the flame sensor:



**Ash Scale:** Used to indicate the level of ash:



**E** Numerical digits.

**F** Alarm icons: Warning.

Boiler lock-out.

## G Special functions icons:

 **Anti-frost function:** This icon blinks when the boiler's anti-frost function is activated.

 **Technical icon:** It is displayed when any of the boiler's technical parameter on the "Technical Menu" or "Setup menu" is displaying or modifying.

## H Auxiliary icons.

 Value or setting related to a temperature is shown by the numerical digits.

**EXT** Value or setting related to the outside temperature is shown by the numerical digits.

**INT** Value or setting related to the room temperature are shown by the numerical digits.

**bar** Value or setting related to the boiler water pressure is shown by the numerical digits.

## I Operating mode icons:

 It is displayed when a value or setting related to the room temperature or room thermostat or remote controls is shown by the numerical digits.

 It is displayed when a value or setting related to OTC operating mode is shown by the numerical digits.

 It is displayed when the direct heating circuit n° 1 demand is activated or when a value or setting related to this circuit is shown by the numerical digits.

 It is displayed when the direct heating circuit n° 2 demand is activated or when a value or setting related to this circuit is shown by the numerical digits.

 It is displayed when the mixing heating circuit n° 1 demand is activated or when a value or setting related to this circuit is shown by the numerical digits. The arrows appear according to the 3 way mixing valve of the circuit activation mode. The upper arrow indicates that the hot channel of the valve is opening, and the lower arrow indicates that the hot channel of the valve is closing.

 It is displayed when the mixing heating circuit n° 2 demand is activated or when a value or setting related to this circuit is shown by the numerical digits. The arrows appear according to the 3 way mixing valve of the circuit activation mode. The upper arrow indicates that the hot channel of the valve is opening, and the lower arrow indicates that the hot channel of the valve is closing.

 It is displayed when any value or setting related to the boiler and/or the burner is shown by the numerical digits.

 It is displayed when a value or setting related to DHW tank is shown by the numerical digits.

 It is displayed when a value or setting related to boiler's fan is shown by the numerical digits.

 It is displayed when a value or setting related to weight, calibration, fuel consumption, etc. is shown by the numerical digits.

 It is displayed when fuel level detection system is activated.

## BioClass NG (For external use)

-  It is displayed when a value or setting related to the burner's ash cleaning system or boiler's ashtray (either manual or compressor) is shown by the numerical digits.
-  It is displayed when a value or setting related to the ashtray overflowing is shown by the numerical digits.
-  It is displayed when a value or setting related to DHW recirculation function is shown by the numerical digits. It displays blinking when the DHW recirculation pump is switched on.
-  It is displayed when the feed auger is switched on and it is displayed blinking when it is in manual operation mode.
-  Display of any value or parameter related to the temperature or operation of the buffer tank.
-  It is displayed when any of the *Menu* is in browse mode.
- SET** It is displayed when the parameter shown by the numerical digits is adjustable and it is displayed blinking when the parameter is in adjustment mode.

## 6 OPERATION

**BioClass NG** is set by default as an "Only Heating" boiler. In option, it is possible to connect a DHW tank and/or a **BIO Hydraulic Kit** to increase the features offered.

### 6.1 "Only heating" operation

In this operation mode, it is needed to set a temperature of the boiler (see *"Boiler temperature set point selection"*), of the room thermostat (**TA1**) or of the **LAGO FB OT+** remote control (if there is any connected) in order to start the boiler up. The burner will start running to heat the water of the boiler. When the temperature of the boiler overtakes 60 °C, the heating pump is switched on to heat the water of the installation. The burner modulates the heat output level to maintain the set point temperature selected and the pump continues running until the installation reaches to the temperature selected in the room thermostat or remote control (if there is any connected). When the temperature in the boiler overtakes 4 °C the boiler set point temperature the burner stops until the temperature decreases 10 °C behind the set point temperature, in this moment the burner is switched on again.

It is possible to disable the heating service (*Summer* mode) by setting to "oFF" the boiler temperature set point. In this operating mode only the DHW service is available if there is a DHW tank installed.

**NOTE: When the heating service is disabled, they will be disabled all the circuits of the BIO Hydraulic Kit, if there is any connected.**

### 6.2 Operating with a Sanit DHW storage tank (Option)

**BioClass NG** boiler could be installed together with a DHW tank **Sanit**, within the product range offered by **DOMUSA**, to obtain Domestic Hot Water service. Follow the instructions described in section *"Installing a Sanit hot water tank"* to assure a correct installation.


In this operating mode, it is needed to set a DHW temperature set point (see *"DHW temperature set point selection"*) in order to start DHW service up. The burner will start running and the DHW pump or valve will switch on if the boiler's temperature overtakes 60 °C and it is higher than the one into DHW tank. When DHW tank temperature reaches the set point temperature, after a postcirculation period of time (parameter **P.16** of "Technical Menu"), the boiler will be able to heat the heating installation by switching on the heating pump. The burner modulates the heat output level to maintain the boiler temperature set point. The heating pump will stop when the room temperature reaches the set point set at the room thermostat or remote control (if there is any connected).

It is possible to disable the DHW by setting to "oFF" the DHW temperature set point.

**NOTE: To assure the optimal DHW service, the heating service will not be available while the DHW service is activated to heat the DHW tank.**

# BioClass NG (For external use)

## 6.3 Boiler temperature set point selection




Boiler temperature set point selection is made by the tactile selector shown in the picture. Press "+" and "-" buttons to increase or decrease the set point desired. Few seconds after the desired set point temperature is adjusted the display returns to main position. The range of values for boiler temperature set point is OFF, 65 - 80 °C.

It is also possible to set boiler temperature set point browsing through the "User Menu" by pressing **MENU** button. When parameter "Boiler set point temperature" is displayed, the boiler temperature set point is set by pressing "+" and "-" buttons.

When the "OTC operating mode" is activated by means of **P.10** parameter of "Technical Menu" and the K-factor is set for the heating circuit of the boiler (or direct heating circuit of **BIO Hydraulic Kit**), the boiler temperature set point is calculated depending on the K-factor selected. The boiler temperature set point parameter only allows to set between activating ("on") or deactivating ("OFF") the heating service.

It is possible to disable the heating service of the boiler (**Summer** mode) by setting to "OFF" the boiler temperature set point by pressing "-" symbol for heating (**18**).

## 6.4 DHW temperature set point selection (with DHW tank installed only)




DHW temperature set point selection is made by the tactile selector shown in the picture. Press "+" and "-" buttons to increase or decrease the set point desired. Few seconds after the desired set point temperature is adjusted the display returns to main position. The range of values for DHW temperature set point is OFF, 15 - 65 °C.

It is also possible to set the DHW temperature set point browsing through the "User Menu" by pressing **MENU** button. When parameter "DHW temperature set point" is displayed, the DHW temperature set point is set by pressing "+" and "-" buttons.

It is possible to disable the DHW service by setting to "OFF" the DHW temperature set point by pressing "-" for DHW (**19**).

## 6.5 Selecting the setpoint temperature of the buffer tank (only with buffer tank)



The desired buffer tank temperature is selected using the touch button, as shown in the figure. To select the desired temperature, touch the "+" or "-" symbols to increase or decrease the temperature. When the temperature has been selected, the display will return to standby mode after a few seconds. The permitted range of setpoint temperature is OFF, 30 - 80 °C.

The buffer tank setpoint temperature can also be selected by using the touch button MENU to browse to the display option *"Buffer tank setpoint temperature"*. When this option appears on the display, touch the "+" or "-" symbols to select the desired temperature.

If you wish to totally disable the central heating function of the installation (**Summer** mode), select the setpoint value **"OFF"**, by touching the "-" symbol until this value appears on the display.

## 6.6 Fuel level detection system operation

**BioClass NG** boiler integrates a fuel level detection system into the hopper, in order to prevent it from running out of pellets. It is composed by a level sensor assembled inside the hopper and 2 outputs for connecting warning devices, if it is required. The detection system operates as follows:

- When the level sensor detects a low level of pellets (fuel reserve level), the boiler displays the alarm code **E-48** on the screen (and on the screen of **Lago FB OT+** remote controller, if there is any connected) and activates the outputs connected to terminal strips **J8** and **J9** of the main board, warning the user for re-filling the hopper with pellets if any warning device is connected to any of them.
- The boiler continues working until the fuel reserve is consumed. The fuel reserve is measured in pellets mass and corresponds to one hour of consumption of the boiler at 100% of its heat output level, so the length of this period depends on the modulation level at what the boiler works.
- Refilling the hopper with pellets up to the sensor level will reset the alarm code **E-48** and deactivate the devices connected to terminal strips **J8** and **J9** of the main board, if there is any.
- When the pellets reserve is consumed the boiler displays the alarm code **E-49** and stops working in order to prevent the hopper from running out of fuel completely, avoiding to have to re-calibrate it. The devices connected to terminal strips **J8** and **J9** of the main board (if there is any) remain activated, warning the user for re-filling the hopper.
- To reset the alarm code **E-49** and restore the boiler functioning, first the hopper has to be refilled with pellets up to the sensor level and, after that, pushing the **RESET** button the alarm code **E-49** will be reset and the boiler will restart working.

To connect any warning device to fuel level detection system follow carefully the instructions indicated in the sections *"Installing the Hopper"* and *"Electrical Connection Diagram"* of this manual.


# BioClass NG (For external use)

## 6.7 Functioning according to Outdoor Temperature Conditions OTC (option)

When the boiler is installed together with a **BIO Hydraulic Kit** and an outdoor temperature sensor AFS is connected in the Kit, the OTC operation mode could be activated by means of **P.10** parameter at the *"Technical Menu"*.

When this operation mode is activated, the boiler and/or heating flow temperature are automatically adjusted in accordance with the K-factor curve set at the *"Technical Menu"* (parameters **P.11** and **P.12**) and the outdoor temperature measured by the outdoor sensor. If the installation is correctly dimensioned, the boiler temperature and/or flow temperature calculated will ensure the room temperature set point set at room thermostat or remote control (if there is any connected).

The K-factor curve relates the outdoor temperature, measured by the sensor installed outside the building, with the boiler temperature set point. The diagram shows the temperature value for each point on the K-factor curve.



Depending on the type of heating circuit, isolation of the building and position of the outdoor sensor, the optimal K-factor curve could be different. Nevertheless, a general rule could be that for high temperature heating circuits (radiators heating circuit) the K-factor curve should be 1 or higher and for low temperature heating circuits (underfloor heating circuit) it should be 0.8 or less.

**IMPORTANT:** To connect the outdoor sensor AFS to BIO Hydraulic Kit, follow the connection instructions provided within the Kit.

## 7 OPERATING WITH BIO HYDRAULIC KITS (OPTIONAL)

All the models within **BioClass NG** range of boilers may be installed together with a **BIO Hydraulic Kit** to regulate more than one heating circuit. Up to 3 heating circuits and a DHW circuit can be managed depending on the **BIO Hydraulic Kit** chosen. For a detailed description of the functioning of the Kit, read the manual supplied within the Kit. Nevertheless the following guidelines are given:

### Direct circuit functioning (P.23)

When the **BIO Hydraulic Kit** installed has a direct circuit pump (**Bcd**), by means of parameter **P.23** of the *“Technical Menu”* its operation mode may be selected:

**P.23 = 0** => Operating as a heating pump (by default).

**P.23 = 1** => Operating as a DHW charging pump.

When the direct circuit pump is configured for heating circuit operation mode (**P.23 = 0**) it will work with the selected boiler temperature set point and the temperature of the room thermostat **TA1** or a LAGO FB OT+ remote control, both connected to the terminal strip of the boiler (see *“Connections diagram”*). When the **BIO Hydraulic Kit** is operating with an outdoor temperature sensor, by means of parameter **P.10** OTC operation mode (Outdoor Temperature Control) may be selected for the direct circuit. OTC mode allows the boiler temperature setting depending on the K-factor curve set at **P.11** or **P.12** parameter and the actual outdoor temperature read by the sensor.

When the direct circuit pump is configured as a DHW tank charging pump (**P.23 = 1**), the direct circuit will work according to the DHW temperature set point selected on the boiler main board and the temperature read by the DHW sensor **Sa** installed into the tank.

In both cases, the burner and circulating pump will start operating (**Bcd** of the **BIO Hydraulic Kit**) until the temperature set point is reached in the boiler or in the DHW storage tank.

### Mixing circuit n° 1 functioning

The mixing heating circuit No 1 will work together with the flow temperature set point adjusted for circuit No 1 and the temperature of the room thermostat or LAGO FB OT+ remote control connected in the **BIO Hydraulic Kit** (see *“Connection diagram”* of the **BIO Hydraulic Kit** instructions manual). When the **BIO Hydraulic Kit** is operating with an outdoor temperature sensor, by means of parameter **P.10** OTC operation mode (Outdoor Temperature Control) may be selected for the direct circuit. OTC mode allows the boiler temperature setting depending on the K-factor curve set at **P.11** parameter and the actual outdoor temperature read by the sensor.

### Mixing circuit n° 2 functioning

The mixing heating circuit No 2 will work together with the flow temperature set point adjusted for circuit No 2 and the temperature of the room thermostat or LAGO FB OT+ remote control connected in the **BIO Hydraulic Kit** (see *“Connection diagram”* of the **BIO Hydraulic Kit** instructions manual). When the **BIO Hydraulic Kit** is operating with an outdoor temperature sensor, by means of parameter **P.10** OTC operation mode (Outdoor Temperature Control) may be selected for the direct circuit. OTC mode allows the boiler temperature setting depending on the K-factor curve set at **P.12** parameter and the actual outdoor temperature read by the sensor.

### 8 OPERATION WITH A BT BUFFER TANK (OPTIONAL)

The **BioClass NG** boiler can be accompanied by a **BT Buffer tank** from the wide range of tanks offered by **DOMUSA**. This tank accumulates heat energy that improves the performance of the system when switching the boiler on and off. For its correct installation, carefully follow the assembly instructions included with the tank and for its correct integration with the **BioClass NG** boiler, read the instructions in the section "*Installing a BT Buffer tank*" in this manual.

The electronic control of the **BioClass NG** boiler is able to manage four different installation configurations of the BT buffer tank. Depending on the configuration of the installation (parameter **P.08** in the "Technician" menu) there are 2 operating modes:

#### 8.1 Operation with a temperature sensor in the BT buffer tank (P.08 = 1 or 2)

In this operating mode you must select the desired setpoint temperature of the buffer tank (*see "Selecting the buffer tank setpoint temperature"*) and the temperature of the the room thermostat No. 1 (**TA1**) or remote control **LAGO FB OT+** (if present). The burner will start working to heat the water in the boiler. When the boiler temperature exceeds 60 °C the feed pump for the buffer tank (**Bbt**) will start up to heat the BT tank. The modulating burner of the **BioClass NG** boiler will keep the water in the buffer tank at the set temperature. When the temperature of the tank reaches the selected set point temperature the burner will shut down until its temperature drops to the value set in parameter **P.28** (by default 5 °C) below that desired, once again starting a new heating cycle.

Regarding the central heating service of the boiler, the circulation pump (**BC**) will be activated whenever room thermostat No. 1 (**TA1**), or the remote control **LAGO FB OT+** (if present), demands heating. In other words, when the room temperature where the thermostat or the remote control is installed is lower than that which is set. When the atmosphere reaches the desired temperature and after a time of post-circulation (parameter **P.15** in the "Technician Menu"), the operation of the heating pump (**BC**) will turn off.

The boiler's central heating service can be totally disabled (*Summer* mode) by selecting a buffer tank setpoint value of "**OFF**". In this operating mode, only the DHW production function will remain enabled, providing there is a DHW tank connected to the tank (**P.08 = 1**) or to the boiler (**P.08 = 2**).

**NOTE:** When the heating function is disabled, all the circuits of the BIO hydraulic Kit will also be disabled, if connected.

**NOTE:** This operating mode is only activated when parameter P.08 of the "Technician" menu is set to 1 or 2 and when there is a buffer tank installed.

## 8.2 Operation with a control thermostat in the BT buffer tank (P.08 = 3 or 4)

In this operating mode you must select the desired setpoint temperature of the boiler (*see "Selecting the boiler setpoint temperature"*) and, using the control thermostat installed in the buffer tank, you must also select the desired setpoint temperature in the buffer tank. **It is essential for the operation of the installation that the setpoint temperature selected for the boiler exceeds the setpoint selected for the control thermostat of the buffer tank and it is recommended that it be at least 5 to 10 °C higher.** The modulating burner of the **BioClass NG** boiler will start working to heat the water within it. When the boiler temperature exceeds 60 °C the feed pump for the buffer tank (**Bbt**) will start up to heat the BT tank, provided that its control thermostat is activated (demanding heating). When the buffer tank thermostat reaches the desired temperature and turns off the heating demand, operation of the buffer tank feed pump (**Bbt**) will be disabled.

Regarding the central heating service of the boiler, the circulation pump (**BC**) will be activated whenever room thermostat No. 1 (**TA1**), or the remote control **LAGO FB OT+** (if present), demands heating. In other words, when the room temperature where the thermostat or the remote control is installed is lower than that which is set. When the atmosphere reaches the desired temperature and after a time of post-circulation (parameter **P.15** in the "Technician Menu"), the operation of the heating pump (**BC**) will turn off.

The boiler's central heating service can be totally disabled (**Summer** mode) by selecting a boiler setpoint value of "**OFF**". In this operating mode, only the DHW production function will remain enabled, providing there is a DHW tank connected to the tank (**P.08 = 3**) or to the boiler (**P.08 = 4**).

**IMPORTANT:** It is essential for the operation of the installation that the setpoint temperature of the boiler exceeds the setpoint selected for the control thermostat of the buffer tank.

**NOTE:** When the heating function is disabled, all the circuits of the BIO hydraulic Kit will also be disabled, if connected.

**NOTE:** This operating mode is only activated when parameter P.08 of the "Technician" menu is set to 3 or 4 and when there is a buffer tank installed.

### 9 OPERATION WITH A BT-DUO BUFFER TANK (OPTIONAL)

The **BioClass NG** boiler can be accompanied by a **BT-DUO Buffer tank** from the wide range of tanks offered by **DOMUSA**. This tank accumulates heat energy that improves the performance of the system when switching the boiler on and off. It also incorporates a DHW cylinder in its interior for obtaining Domestic Hot Water. For its correct installation, carefully follow the assembly instructions included with the tank and for its correct integration with the **BioClass NG** boiler, read the instructions in the section *"Installing a BT-DUO Buffer tank"* in this manual.

In this operating mode you must select the desired setpoint temperature of the boiler (*see "Selecting the boiler setpoint temperature"*) and, using the adjustment thermostat of the control panel in the BT-DUO buffer tank, you must also select the desired setpoint temperature in the buffer tank. **It is essential for the operation of the installation that the setpoint temperature selected for the boiler exceeds the setpoint selected for the thermostat of the BT-DUO buffer tank and it is recommended that it be at least 5 to 10 °C higher.** The modulating burner of the **BioClass NG** boiler will start working to heat the water within it. When the boiler temperature exceeds 60 °C the feed pump for the buffer tank will start up to heat the BT-DUO tank, provided that its control thermostat is activated (demanding heating). When the BT-DUO tank thermostat reaches the desired temperature and turns off the heating demand, the operation of its feed pump will be disabled.

Regarding the central heating service of the boiler, the circulation pump connected to it (**BC**) will be activated whenever room thermostat No. 1 (**TA1**), or the remote control **LAGO FB OT+** (if present), demands heating. In other words, when the room temperature where the thermostat or the remote control is installed is lower than that which is set. When the atmosphere reaches the desired temperature and after a time of post-circulation (parameter **P.15** in the "Technician Menu"), the operation of the heating pump (**BC**) will turn off.

Regarding the operation of the service for providing DHW, provided that a DHW temperature sensor is installed in the **BT-DUO** tank, you must select the desired DHW setpoint temperature (*see "Selecting the DHW setpoint temperature"*). The burner will ignite and the feed pump for the **BT-DUO** tank will be activated whenever the water temperature of the boiler exceeds 60 °C. When the tank reaches the DHW setpoint temperature selected and after a waiting period (parameter **P.16** in the "Technician Menu"), it will once again be available to heat the central heating system, activating the central heating service. In order to provide an optimal production of DHW, while this is active the boiler's central heating service will remain disabled and it will not be restored until it has finished heating the DHW cylinder of the **BT DUO** tank.

The boiler's central heating service can be totally disabled (**Summer** mode) by selecting a boiler setpoint value of **"OFF"**. In this operating mode, only the DHW production function will remain enabled, via the cylinder integrated inside the **BT-DUO** tank. Also, you may totally disable the domestic hot water production function by selecting **"OFF"** as the DHW setpoint temperature.

**IMPORTANT:** It is essential that the setpoint temperature of the boiler exceeds the setpoint selected for the control thermostat of the buffer tank.

**NOTE:** When the heating function is disabled, all the circuits of the BIO hydraulic Kit will also be disabled, if connected.

**NOTE:** For the correct operation of the BT-DUO buffer tank, parameters P.08 and P.09 in the "Technician" menu must be set to 4 and 0 respectively.

## 10 OPERATING WITH LAGO FB OT+ REMOTE CONTROLLER (OPTIONAL)

A remote control (**LAGO FB OT+**) can optionally be supplied together with **BioClass NG** boiler. This remote control can be used to fully operate the boiler from anywhere in the room in which it is installed. The **LAGO FB OT+** remote control regulates the parameters of heating circuit and the domestic hot water production.

This remote control allows the hours of comfort to be programmed for heating circuit, regulating the installation to the particular requirements of the building by measuring the room temperature and consequently adapting the installation temperature. The remote control can also be used to regulate the hot water and heating temperatures set point at any time, and for viewing the different boiler operation parameters. It also warns of any functioning anomalies affecting the boiler.

The **LAGO FB OT+** remote control may optionally be connected to an outdoor temperature sensor, for measuring the temperature around the building. With this option installed, the remote control can adjust the building comfort level according to the weather conditions, optimising fuel consumption and heating comfort in the building.

The **LAGO FB OT+** remote control takes over the control of the boiler when it is connected. The different selectable temperatures boiler of the boiler must be set at the remote control. It is easy to install, requiring only 2 wires for communication between the boiler and the **LAGO FB OT+** control, by connecting the two wires on terminal strip **J5** (see *"Electrical Connection Diagram"*). For a correct installation and functioning, read carefully the instructions within the remote control.

The following sections contain a general explanation of the different operating modes and options of **LAGO FB OT+** remote control.

### Operation of the heating circuit

The maximum temperature for heating circuit, the operating period of time and the desired room temperature can be set at remote control. **LAGO FB OT+** remote control will calculate the boiler temperature required at each particular time, depending on the temperature of the room and it will activate or deactivate the heating demand depending on the heating times and room temperatures programmed.

### DHW service function


When **BioClass NG** boiler is installed together with a DHW tank the desired DHW temperature and the desired periods of time for DHW service must to be set at **LAGO FB OT+** remote control. **LAGO FB OT+** remote control regulates the DHW tank temperature and enables or disables the DHW service according to the time periods scheduled.


# BioClass NG (For external use)

## 11 USER MENU

"User Menu" shows the settings related to boiler functioning on the digital display.

To access this menu press MENU; press this button repeatedly to browse through the different settings available. When one of the options is displayed, after 20 seconds the display returns to main position. In the following table are listed all the settings of "User Menu".





## 11.1 Ashtray status

When "Ashtray Empty Warning" function is activated (see "Setup menu"), the boiler warns about the ashtray is full and must be emptied. The parameter "Ashtray status" allows checking the fill level and the screen shows the ash scale bar which indicates the fill level of the ashtray. When it is full, an "Empty the ashtray" warning is activated. Whenever the ashtray is emptied, it is necessary to set the "Ashtray status" parameter to "0" by pressing "-" for DHW **(19)**.

The display of the notices is as follows:

-  : Ashtray fill level between 0 and 75 %.
-  flashing: Ashtray fill level between 75 and 100 %.
-  and  flashing: Ashtray fill level more than 100 %.

# BioClass NG (For external use)

## 12 SETUP MENU

"Setup menu" consists of operating parameters of the boiler which can be adjusted by the user (Ashtray empty warning, timer programming, time setting, ...)


To access to the "Setup menu" press . Browse through the menu by pressing the symbols "+" or "-" of heating (18). When a parameter is displayed, press to access and set it. When the parameter has been set, press again, the new value will be saved and the display will return to "Setup menu". Press RESET any time to go back without recording any value. In the following table are listed all the parameters of "Setup menu".

Nº.	Parameter	Display
1	Boiler timer programming.	
2	DHW recirculation function timer programming. (DHW tank option only)	
3	Time setting.	
4	Ashtray empty warning function.	
5	Manual setting of feed auger calibration.	
6	Screen contrast setting.	


## 12.1 Timers programming process

**BioClass NG** boiler allows setting 2 different timers: boiler timer and DHW recirculation pump timer (if this function is activated on the *“Technical Menu”*). The default setting for the timers is disabled (“- - - -”), so the functioning that is regulated by each timer will operate 24 hours. The programming process is the same for any timer.


When the desired timer is displayed, press  to access. SET symbol blinks to start the setting process:



Select the time periods (30 minutes periods) by pressing "+" or "-" of heating **(18)**.




When the period desired is selected, change it state by pressing "+" or "-" of DHW **(19)**. The function will be switched off if symbol ☾ is displayed and it will be switched on if symbol ☀ is displayed.



After setting all the periods desired, press  to save and return to *“Setup menu”* level.


## 12.2 Boiler timer programming

This timer is used to adjust the switching on and off periods of the boiler functioning. To disable the timer, select boiler timer programming  and set it to “- - - -” by pressing “-” of the boiler temperature touch button **(18)**. The boiler timer will be cancelled and it will be switched on permanently.



## 12.3 DHW recirculation function timer programming (DHW tank option only)


This timer is only displayed when the DHW recirculation function is selected in the multifunction relay parameter (P.20 = 2) of the *“Technical Menu”*. It is used to adjust the switching on and off periods of DHW recirculation pump. To disable the timer, select the DHW recirculation timer programming  and set it to “- - - -” by pressing “-” of the boiler temperature touch button **(18)**. The timer will be cancelled and the pump will be switched on permanently.




# BioClass NG (For external use)

## 12.4 Time setting

When "Time setting" parameter of "Setup menu" is displayed, press  to access. The first two digits of numerical digits blinks (hours) and setting process begins:



Set the hour value by pressing "+" or "-" of DHW (19). Pressing  the value is saved and the minutes digits blinks to set them.



Set the minutes value by pressing "+" or "-" of DHW (19). Pressing  the value is saved and it returns to "Setup menu" level.

## 12.5 Ashtray empty warning function

When this function is activated, the boiler's controller warns about the ashtray of the boiler is full and must be emptied, depending on boiler's fuel consumption (kg). The parameter "Ashtray status" of "User Menu" allows checking the actual fill level. When it is full, an "Empty the ashtray" warning is activated.

By default this function is supplied activated and set to a general default rough value, so it should be adjusted depending on the quality and type of fuel used. The following table shows the default value of this parameter in kilograms of fuel consumption (depending of boiler model):

Model	Fuel Kg
BioClass NG 16	750 kg


Select "Ashtray empty warning" (🔥) parameter of "Setup menu" and press 🔧 to access. The value is set by pressing "+" and "-" symbols of DHW (19). It is possible to deactivate this function by setting the value of this parameter to "OFF".



**NOTE: Each time a new value is set for this parameter, the ashtray must be emptied.**


## 12.6 Manual setting of feed auger calibration

When this parameter is displayed (🔧) on "Setup menu", press 🔧 to access and set the value desired by pressing "+" or "-" of DHW (19). The range of values selectable is OFF, 0.500 - 5.000 kg.



## 12.7 Screen contrast setting

When this parameter of the "Setup menu" is displayed, press 🔧 to access and set the value desired by pressing "+" or "-" of DHW (19). The range of values selectable is 1 - 5.





# BioClass NG (For external use)

## 13 CALIBRATION MENU

"*Calibration Menu*" consists of a number of processes and parameters that allow the correct set up of the boiler.


To access the "*Calibration Menu*", the boiler must be switched off by pressing  tactile button. After having switched off the boiler press  for 5 seconds to access to the menu. Browse through the menu by pressing the symbols "+" or "-" of heating (18). When the desired parameter is displayed, press  to access and set it. When the parameter or process has been set, press  again, the value will be saved and the display will return to "*Calibration menu*". Press RESET any time to go back without recording any value. In the following table are listed all the parameters and processes included in "*Calibration menu*".

N°.	Parameter	Display
1	Feed auger filling	
2	Feed auger calibration	
3	Manual setting of feed auger calibration	
4	Manual ash cleaning activation	
5	Manual circulation pumps activation	


### 13.1 Feed auger filling

During the commissioning of the boiler, before calibrating the feed auger or if the hopper runs out of fuel, **it is compulsory** to fill of fuel the feed auger. By means of this parameter the feed auger will be filled of fuel, process required for a correct boiler functioning.

When "Feed auger filling" parameter is displayed (🔧) on "Calibration Menu", press 🔧 to access. SET symbol blinks and pressing 🔧 again it will be activated filling procedure. The feed auger will be activated and a count up to 15 minutes (maximum) will be displayed. During the process by pressing 🔧 the feed auger could be stopped at any time and by pressing RESET the filling procedure could be finished and return to "Calibration Menu" at any time.



To ensure a complete filling of boiler feed auger it is recommended to make a complete 15 minute procedure of filling, at least once. Follow the steps shown in the following pictures for a correct filling of the feed auger:




**IMPORTANT:** It is compulsory to fill the feed auger during the commissioning or when the hopper runs out of fuel.

# BioClass NG (For external use)


## 13.2 Feed auger calibration

By means of calibrating the feed auger the electronic controller of the boiler adjusts the optimum amount of fuel required to supply the burner and to produce the correct heat output and combustion. By means of this parameter the feed auger calibration procedure will be made, process required for a correct boiler functioning. **In any case the hopper is empty or it runs out of fuel, it is compulsory to fill the feed auger before carrying out the calibration process. It is compulsory to calibrate the feed auger on commissioning and whenever the fuel supplier is changed** (not all suppliers provide fuel of the same quality and size).

When "Feed auger calibration" parameter is displayed (🗑️) on "Calibration Menu", press 🔧 to access. SET symbol blinks and pressing 🔧 again it will be activated calibration procedure. The feed auger will be activated and a countdown from 200 doses will begin. When the countdown finishes current calibration value will be displayed, press 🔧 to adjust the new value obtained during the procedure by pressing "+" or "-" symbols of DHW (19). Finally pressing 🔧 the value will be saved and it will return to Calibration Menu level.




This process must be carried out at least twice to ensure the correct amount of fuel has been added. Follow the steps shown in the following pictures for a correct calibration of the feed auger:



**IMPORTANT:** Calibrate the feed auger during commissioning of the boiler or whenever the fuel supplier has been changed.


### 13.3 Manual setting of feed auger calibration

By means of this parameter the weight obtained in the feed auger calibration procedure can be set manually. When "Manual setting of feed auger calibration" parameter is displayed () on "Calibration Menu", press  to access and set the value desired by pressing "+" or "-" of DHW (19). The range of values selectable is OFF, 0.500 - 5.000 g.



### 13.4 Manual ash cleaning activation


By means of this parameter the burner ash cleaning device can be switched on manually up to a maximum of 20 cleaning cycles. When "Manual ash cleaning activation" parameter is displayed () on "Calibration Menu", press  to access. SET symbol blinks and pressing  again it will be activated the cleaning system. A countdown of 20 cycles will be displayed. When the countdown is finished the cleaning device will stop. By pressing  the cleaning procedure can be stopped at any time and by pressing RESET it will return to "Calibration Menu" level.



### 13.5 Manual circulation pumps activation

By means of this parameter the circulation pumps can be switched on manually. When "Manual circulation pump activation" parameter is displayed () on "Calibration Menu", press  to access. SET symbol blinks and pressing  again the circulation pumps will be activated for a period of not more than 20 minutes.

By pressing  the circulation pumps can be stopped at any time and by pressing RESET it will return to "Calibration Menu" level.



















## 14 TECHNICAL MENU

"Technical Menu" consists of a number of technical operating parameters that only have to be modified by a person with sufficient technical knowledge of the meaning of each parameter. Any inappropriate setting of a parameter of "Technical Menu" can cause a serious malfunctioning of the boiler and could cause damages to people, animals or things.








**To access the "Technical Menu"** press MENU and RESET tactile buttons together for 5 seconds. Access code ("cod") request will be displayed (see "Entry and set the access code"). After entering the correct code, the first parameter of "Technical menu" will be displayed. Browse through the menu (P.01, ..., P.25) by pressing the symbols "+" or "-" of heating (18). When the desired parameter is displayed, press  to access and set it by pressing the symbols "+" or "-" of DHW (19). When the parameter has been set, press  again, the value will be saved and the display will return to "Technical menu". Press RESET any time to go back without recording any value. The following table lists these parameters and they are described in detail in the following sections of the manual:

## BioClass NG (For external use)

N°	Parameter	Display
<b>Cod</b>	Access code (by default 1234)	
<b>P.01</b>	Boiler model	
<b>P.02</b>	Minimum boiler heat output (%)	
<b>P.03</b>	Maximum boiler heat output (%)	
<b>P.04</b>	General fan speed factor (%)	
<b>P.05</b>	Fuel for ignition (g)	
<b>P.06</b>	Fuel consumption (kg/h)	
<b>P.07</b>	Fuel type	
<b>P.08</b>	Selecting the type of installation for the BT buffer tank <i>(Only with buffer tank installed)</i>	
<b>P.09</b>	DHW installation mode <i>(DHW tank option only)</i>	


N°	Parameter	Display
P.10	OTC operating mode <i>(Bio Hydraulic kit option only)</i>	
P.11	Heating circuit n. 1 K-factor curve <i>(Bio Hydraulic kit option only)</i>	
P.12	Heating circuit n. 2 K-factor curve <i>(Bio Hydraulic kit option only)</i>	
P.13	Boiler minimum temperature mode	
P.14	Minimum boiler temperature (°C)	
P.15	Heating pump post-circulation time (min)	
P.16	DHW pump post-circulation time (min) <i>(DHW tank option only)</i>	
P.17	Legionella protection function <i>(DHW tank option only)</i>	
P.18	Boiler's pump operating mode (BC)	
P.19	Minimum boiler water pressure (bar)	

## BioClass NG (For external use)

N°	Parameter	Display
P.20	Multifunction relay	
P.21	Automatic water filling pressure(bar) <i>(P.20 = 3 option only)</i>	
P.23	<b>BIO Hydraulic Kit</b> direct pump operating mode <i>(BIO Hydraulic Kit option only)</i>	
P.24	Reset default values	
P.25	Set access code	
P.26	Auxiliary parameter for fuel selection	
P.27	Maximum heating flow temperature of mixed circuits <i>(Only with the optional Hydraulic Kit Bio)</i>	
P.28	BT buffer tank temperature hysteresis <i>(Only with buffer tank installed)</i>	

### 14.1 Entry and set the access code ("cod", P.25)

When the access code request is displayed or to set a new one (P.25), press  to access. SET symbol blinks and it would be possible to enter the code or set it. Press the "+" o "-" for heating symbols (18) to browse trough the digits and press the "+" o "-" for DHW symbols (19) to set each digit. By default, the access code is "1234". The P.25 parameter allows to set a new access code.



## 15 BOILER'S SETUP PARAMETERS

The following parameters in the "*Technical Menu*" allow to adjust the boiler to each installation. They only may be modified by a person with sufficient technical knowledge of the meaning of each parameter. Any inappropriate setting of a parameter of "*Technical Menu*" can cause a serious malfunctioning of the boiler and could cause damages to people, animals or things.

### 15.1 Boiler Model (P.01)

Parameter **P.01** displays the model of the boiler set at DIP-switch on the electronic board.

**P.01 = 16 => BioClass NG 16**

**P.01 = 25 => BioClass NG 25**

### 15.2 Boiler heat output (P.02, P.03)

**BioClass NG** boiler is configured to modulate between a minimum and a maximum burner heat output. By means of parameters **P.02** and **P.03** the minimum and maximum heat output of the burner may be set at desired value. The range of modulation selectable depends on the model of boiler and the type of fuel set.

### 15.3 General fan speed factor (P.04)

By means of parameter **P.04** the fan speed percentage may be set, in order to increase or decrease the combustion air quantity and ensure a correct combustion. Changing its value affects the fan speed percentage for the entire modulation curve. If it is set below 100 % the air quantity will decrease and if it is set a higher value the air quantity will increase. The range of values selectable is 0 - 200 % (by default 100%).

### 15.4 Fuel for ignition (P.05)

By means of parameter **P.05** the amount of fuel for burner ignition procedure may be set at desired value. The default value depends on the model of boiler and the type of fuel set. The range of values selectable is 0 - 900 g.

### 15.5 Fuel consumption (P.06)

By means of parameter **P.06** the amount of fuel consumed by the boiler at 100% heat output may be set, in kilograms per hour. This parameter is related to the boiler model (heat output) and the type of fuel used, as well as its calorific value. The range of values selectable is 1.00 - 30.00 kg/h.

### 15.6 Fuel type (P.07)

By default **BioClass NG** boiler is configured to burn wood pellets. By means of parameter **P.07** another type of fuel may be selected:

**P.07 = 0 => Wood pellet.**

## BioClass NG (For external use)

### 15.7 Managing BT and BT-DUO buffer tanks (P.08, P.28)

Parameter **P.08** is used to set the type of hydraulic installation that has been used for the **BT** or **BT-DUO** buffer tank. This parameter depends on the installation and must be set by the installer once the buffer tank has been assembled. The factory default value is 0, management function of BT buffer tanks disabled. The electronic control of the **BioClass NG** boiler is able to manage the operation of 4 different types of installation.

**P.08** = 0 => Function disabled (default value).

**P.08** = 1 => Installation with Sanit DHW tank after BT tank and control by temperature sensor.

**P.08** = 2 => Installation with Sanit DHW tank before BT tank and control by temperature sensor.

**P.08** = 3 => Installation with Sanit DHW tank after BT tank and control by thermostat.

**P.08** = 4 => Installation with Sanit DHW tank before BT tank and control by thermostat.

When the installation type **1** or **2** is selected, by means of parameter **P.28**, it is possible to adjust the hysteresis of temperature for the sensor **Sbt**, in order to set the temperature to start up and stop the BT buffer tank heating operation. The parameter **P.28** can be adjusted between 5 and 40 °C and by default it is set to 5 °C.

### 15.8 Auxiliary parameter for fuel selection (P.26)

By means of parameter **P.26** the combustion may be set to the fuel characteristics. This parameter is related to the boiler model (heat output) and the type of fuel used. The range of values selectable is 0.000 - 99.99 kg/h and the default value depends on the model of boiler and the type of fuel set:

### 15.9 Boiler minimum temperature mode (P.13, P.14)

By means of parameters **P.13** and **P.14** a different mode of temperature managing may be set (by default **P.13** = **2**), if heating or/and DHW services are enabled. When parameter **P.13** is set to 0, by parameter **P.14** the minimum temperature can be selected as desired, between 30 and 60 °C. The following regulation modes of minimum temperature can be selected:

**P.13** = 0 => Maintains the minimum temperature set at **P.14** parameter.

**P.13** = 1 => Maintains the boiler temperature set point.

**P.13** = 2 => Does not maintain any boiler temperature.

## 16 HEATING CIRCUIT'S SETUP PARAMETERS

**BioClass NG** is equipped with an electronic controller to manage efficiently the automatic functioning of the boiler. It also has the following additional parameters to regulate the heating circuit connected. They only may be modified by a person with sufficient technical knowledge of the meaning of each parameter. Any inappropriate setting of a parameter of "*Technical Menu*" can cause a serious malfunctioning of the boiler and could cause damages to people, animals or things.

### 16.1 Heating pump post-circulation time (P.15)

This function keeps the heating pump (**BC**) running for a period of time after deactivating the heating service, to avoid the overheating due to the temperature inertias of the heating installation. By means of parameter **P.15** the period of time that the pump continues to operate may be set. The range of values selectable is 0 - 40 minutes (by default 3 minutes).

## 16.2 Boiler's pump operating mode (P.18)

The electronic controller allows to select between two operating modes of boiler's circulating pump (**BC**) by means of **P.18** parameter of the *“Technical Menu”*. The following operating modes can be selected:

- P.18 = 0** => Standard mode: The circulation pump will be run depending if the heating demand is activated or not.
- P.18 = 1** => Continuous mode: The pump continues to run provided that the heating mode is enabled (boiler temperature set point different to OFF). If there is room thermostat or remote control connected to the boiler, the electronic controller will regulate the burner functioning according to the heating demand, keeping the pump running continuously.

## 16.3 Minimum boiler water pressure (P.19)

**BioClass NG** is equipped with a water pressure sensor that makes possible to know the pressure of the boiler. If the pressure descends below the value set at **P.19** parameter, the electronic controller locks out the functioning of the boiler and **E-19** alarm code is displayed (see *“Safety lock-outs”*). The range of values selectable is 0.1 - 0.5 bar (by default 0.5 bar).

## 16.4 Maximum heating flow temperature of mixed circuits (P.27)

The electronic controller allows to select the maximum heating flow temperature for mixed circuits installed in the boiler with an optional Bio Hydraulic Kit. By means of parameter **P.27** the maximum heating flow temperature may be set. The range of values selectable is 45 - 80 °C (by default 45 °C for mixed circuits)).

# 17 DHW CIRCUIT'S SETUP PARAMETERS

**BioClass NG** is equipped with an electronic controller to regulate a Domestic Hot Water production service, if a DHW tank is connected to the boiler. The following parameters are used to set the parameters related to DHW service. These parameters are only displayed if a DHW tank is connected. They only may be modified by a person with sufficient technical knowledge of the meaning of each parameter. Any inappropriate setting of a parameter of *“Technical Menu”* can cause a serious malfunctioning of the boiler and could cause damages to people, animals or things.

## 17.1 DHW installation mode (P.09)

**BioClass NG** could be set to be connected to a DHW production installation managed by a 3-way DHW diverter valve or by a hot water tank pump. These two operating modes can be selected by means of **P.09** parameter:

- P.09 = 0** => 3-way DHW diverter valve installation.
- P.09 = 1** => Hot water tank pump installation (by default).

## 17.2 DHW pump post-circulation time (P.16)

This function keeps the DHW valve or pump running for a period of time after deactivating de DHW service, to avoid the overheating of the boiler due to the temperature inertias of the DHW installation. By means of parameter **P.16** the period of time that the pump/valve continues to operate may be set. The range of values selectable is 0 - 20 minutes (by default 5 minutes).

## BioClass NG (For external use)

### 17.3 Legionella protection function (P.17)

This option prevents the proliferation of legionella bacteria in the DHW tank. Every 7 days the temperature of tank hot water is increased to 70 °C to kill the bacteria. This function is only active if the boiler is turned on and a DHW tank is connected. By means of parameter **P.17** the protection against Legionella bacteria function may be activate or deactivate. By default this function is set deactivated.

### 17.4 DHW re-circulation function (P.20 = 2)

The multifunction of the auxiliary relay output allows to install a DHW re-circulating pump in DHW hydraulic circuit, in order to increase the comfort of DHW service. To activate this function read "*Multifunction-Relay functions*" section.

## 18 ADDITIONAL FUNCTIONS

**BioClass NG** boiler includes the following additional control functions. They only may be modified by a person with sufficient technical knowledge of the meaning of each parameter. Any inappropriate setting of a parameter of "*Technical Menu*" can cause a serious malfunctioning of the boiler and could cause damages to people, animals or things.

### 18.1 Reset default values (P.24)

In case any parameter is wrongly set or if the boiler works incorrectly, all the original values of the parameters can be reset automatically by selecting "Yes" in **P.24** parameter.

### 18.2 Pumps anti-lock function

This function prevents the boiler circulating pumps from locking if they have been out of use for a long period of time. This system remains enabled while the boiler is plugged into the mains.

### 18.3 Anti-frost function

This function protects the boiler from freezing during cold weather periods. If the boiler temperature drops below 6 °C, the heating pump will start running until the boiler temperature reaches 8 °C. If the boiler temperature continues to drop below 4 °C, the burner will start running, in order to heat the installation. It will continue working until the boiler reaches 15 °C. This system remains on standby while the boiler is plugged into the mains.

### 18.4 Boiler pressure sensor function

This function prevents boiler failure caused by a low or high water pressure level in the boiler. The pressure is detected by a pressure sensor and its value appears on the control panel display (in the "*User Menu*"). When the pressure drops below the pressure set at **P.19** parameter (by default 0.5 bar), the electronic controller locks out the boiler functioning and displays **E-19** alarm code on the screen. When the boiler pressure exceeds 2.5 bar, **HI** alarm code is displayed on the screen, warning about the excess of pressure. When it occurs repeatedly it is recommended calling the nearest **Technical Assistance Service** and draining the boiler water until the pressure is between 1 and 1.5 bar.

In order to avoid damages to the boiler, it is necessary to add antifreeze to the water heating circuit. For long periods of shutdown of the boiler, it is recommended to drain all water from it.

## 18.5 Connecting the LAGO FB OT+ remote control

The boiler has the terminal strip **J5** for connecting the **LAGO FB OT+** remote control (see "*Connection Diagram*") that allows to regulate boiler's heating circuit according to the room temperature, besides adjusting the DHW temperature (as long as the DHW temperature sensor is connected in the boiler).

Installing a **LAGO FB OT+** remote control enables the heating and DHW services to adapt to the scheduled times of use of the installation. It also optimises the installation's functioning, adapting the heating temperature set point to the room temperature, improving the comfort.

## 18.6 Room thermostat connection

The boiler has a terminal strip **J6** for connecting a room thermostat or a room chrono-thermostat (TA<sub>1</sub>, see "*Connection Diagram*") that allows to switch on and off the heating circuit demand according to the actual room temperature. The terminal strip **J6** is supplied with a electrical bridge connecting its terminals, so it will be necessary to remove it before connecting the room thermostat.

Installing a room thermostat will optimise the installation's performance, adapting the heating to building requirements and obtaining enhanced comfort. Also, if the thermostat allows the hours of functioning to be programmed (chronothermostat), it can adapt the heating system to the hours of use of the installation.

## 19 MULTI-FUNCTIONAL RELAY (P.20)

**BioClass NG** is equipped with an auxiliary relay output that may be used to select a series of additional functions that increase the boiler performance, features and comfort of the installation.

Several operating modes may be set at **P.20** parameter of the "*Technical Menu*" to define the "*multi-functional relay*" function. The default value of this parameter is 0 (disabled). The following sections describe the functions that could be set.

### 19.1 Boiler alarms external signal (P.20 = 1)

When this function is selected (**P.20 = 1**) if the boiler shows an error or an operating alarm code the multi-functional relay output will be activated, supplying voltage (230 V~) between terminals no. **4**: "**NO**" and **N** of the terminal strip **J3**, where any external alarm signalling device may be connected to warn of boiler malfunctioning.

When the boiler lockage is reset, the multi-functional relay output will supply voltage again (230 V~) between terminals no. **3**: "**NC**" and **N** of the terminal strip **J3**.

### 19.2 DHW re-circulation function (P.20 = 2)

This function is available only if a DHW tank is connected on the boiler. The DHW recirculation function (**P.20 = 2**) will keep the whole DHW installation hot during the operating periods programmed in the boiler, so when any hot water tap is turned on the hot water will be supplied instantly, increasing the comfort of the DHW installation.

A DHW re-circulation pump will be required to install in the installation. This pump has to be connected in the multi-functional relay output, between the terminals No **4 (NO)** and **N** of the terminal strip **J3** (see "*Connections diagram*"). The hydraulic installation and electrical connection of re-circulation system must be made by qualified personnel.

During the operating periods programmed in the boiler, the multi-functional relay output will be

## BioClass NG (For external use)

activated, supplying voltage (230 V~) between terminals No **4** ("**NO**") and **N** of the terminal strip **J3**, where the recirculation pump must be connected. During the switched off periods programmed the multi-functional relay output will be deactivated, supplying voltage (230 V~) between terminals No **3** ("**NC**") and **N** of the terminal strip **J3** and the re-circulation pump will be stop.

### 19.3 Automatic water filling function (P.20 = 3)

**BioClass NG** boiler may be connected to an automatic water filling system which can be activated or deactivated by **P.20** parameter.


It will be required to install a motorised valve to filling the water between the distribution water and the primary circuit of the boiler. This valve has to be connected in the multi-functional relay output between the terminals No **4** (**NO**) and **N** of the terminal strip **J3** (see "*Connections diagram*"). The hydraulic installation and electrical connection of the automatic water filling system must be made by qualified personnel.

If the function is enabled (**P.20 = 3**) the electronic controller of the boiler will active the multi-functional relay output supplying voltage (230 V~) between the terminals No **4** (**NO**) and **N** of the terminal strip **J3** (see "*Connections diagram*") that activates the connected filling valve to refill the primary circuit up to the pressure set at **P.21** parameter. If the boiler pressure drops below the minimum pressure set at **P.19** parameter the boiler will automatically fill up again until the filling pressure value is reached. The filling pressure range, at **P.21** is 0,6-2,0 bar and the factory default value is 1 bar.

## 20 CLEANING THE ASH DRAWER

**BioClass NG** boiler is equipped with an ash drawer, where the solid residues from the burnt fuel are collected on cleaning procedures of the burner and heat exchanger. This drawer must be regularly cleaned to prevent ash from accumulating and obstructing heat exchanger, what would cause the boiler to block out. It is recommended to check regularly the drawer and remove the ash that is accumulated (see *"Ashtray empty warning function"*).

**DOMUSA** supplies an optional ash compacting device for to be installed within the boiler, so that the ash does not need to be removed so frequently.



### 20.1 Safety warnings:

For **safe handling** of the ash drawer, you should take the necessary safety precautions and wear suitable clothing to protect against possible injury. The following advice should be particularly taken into account:

- **Switch off the boiler** before taking out the ash drawer. It is recommended to take out the ash drawer when no flame is detected in the burner.
- It is recommended to wear insulating **thermal gloves** to protect your hands from any burns from hot parts of the drawer.
- It is recommended you wear a protective **mask** to avoid breathing in any ash particles, particularly in the case of people with allergies or any type of respiratory problems, who should always wear a mask when carrying out ash removal.
- As the ash to be removed from the drawer may be burning or glowing, special precautions should be taken regarding to the type of container it is emptied into. A **metal** container is recommended, if not **the ash should be totally put out** using water or another extinguishing agent.

**DOMUSA** shall not be liable for any damage caused to people, animals or property as a result of incorrect handling of the ash drawer or the ash itself.

**IMPORTANT: The ash drawer must only be cleaned when the boiler is switched off or on pause.**

# BioClass NG (For external use)

## 21 SAFETY LOCK-OUTS


The boiler's electronic controller may activate the following safety lock-outs to stop the boiler functioning in order to prevent serious damages. When any of these lock-outs occur, the boiler will switch off and an alarm code will be displayed on boiler's screen.

**IMPORTANT: If any of the safety lock-outs described below should occur repeatedly, switch off the boiler and put in contact with the nearest official Technical Assistance Service.**

### 21.1 Water overheat safety lock-out (E-11)

When this lock-out occurs "E-11" alarm code (temperature alarm) will appear on the screen. The burner will switch off and stop heating the installation.


This lock-out occurs when the temperature of boiler's water exceeds 110 °C. To unlock it, wait until the temperature drops below 100 °C and press the button of the safety thermostat, located underside of the electrical case of the boiler, after having removed the button cover:



### 21.2 Fuel entrance tube overheat safety cut-out (E-05)

When this lock-out occurs "E-05" alarm code will appear on the screen. The burner will switch off and stop heating the installation.

This lock-out occurs when the temperature of the fuel entrance tube exceeds 80 °C. To unlock it, wait until the temperature drops and press the button on the safety thermostat using a screwdriver or a pen as is shown in the picture below:



### 21.3 Low pressure lock-out

When this lock-out occurs, “E19” alarm code will appear on the digital display. The burner and the boiler's circulation pumps will switch off, cutting off the heating and water flow to the installation.

This lock-out occurs when the pressure of boiler's water drops below the value set at **P.19** parameter of “*Technical menu*” (by default 0.5 bar), preventing the boiler from functioning when the water is drained from the installation, due to either leakage or maintenance operations. To unlock this alarm, fill the installation again (see “*Filling the installation*”) up to 1 or 1.5 bar, displayed on “*Water pressure*” parameter of “*User menu*”.

## 22 SHUTTING DOWN THE BOILER

Press  during 1 second to shut down the boiler. When the boiler is shut down the heating and DHW services are switched off but anti-frost and pumps anti-lock functions continue activated whereas the boiler is kept connected to the power supply and fuel installation.

Unplug the boiler from the power supply and cut out the fuel supply to shut down the boiler completely.

## 23 EMPTYING THE BOILER

Use the drain cock located on the bottom of the boiler to empty it of water. Before opening it, connect a flexible pipe leaded to a sewer. After finishing the procedure, close the cock and remove the flexible pipe.

## 24 BOILER MAINTENANCE

Various maintenance operations should be carried out at different intervals of time to keep the boiler in perfect working order. The yearly maintenance operations should be carried out by personnel authorised by **DOMUSA**.

### 24.1 Frequency of maintenance of the boiler and chimney

The most important aspects to be checked are as follows:

N°	Operation	Frequency
1.	Check the fuel storage.	weekly
2.	Clean the ash in the ash drawer.	as required
3.	Check the boiler visually.	weekly
4.	Check if the feed auger is correctly calibrated.	as required
5.	Check and clean the boiler fume circuit.	yearly
6.	Check and clean the chimney. The chimney must be free of any obstacles and have no leaks.	yearly
7.	Clean the burner.	yearly


## BioClass NG (For external use)

8.	Check the expansion vessel. It must be full, according to its data plate.	yearly
9.	Check the seal between the burner and the boiler.	yearly
10.	Check if the hydraulic circuits are correctly sealed.	yearly
11.	Check the water pressure of the boiler. <b>When the installation is cold</b> , it should be between 1 and 1.5 bar.	yearly

**NOTE:** Depending on the fuel type and weather conditions, it may be necessary to clean the combustion chamber of the burner at a bigger frequency.


### 24.2 Burner cleaning procedure

The following procedure is recommended for a correct cleaning of the burner:



### 24.3 Heat exchanger cleaning procedure

The following procedure is recommended for correctly cleaning the heat exchanger:



## BioClass NG (For external use)

### 24.4 Draining the condensate water

The draining device to take out the condensate water from the chimney should not be altered in any way and it must be kept free of obstructions.

### 24.5 Boiler water characteristics

In areas with water hardness of over 25-30 °fH, treated water must be used in the heating installation to avoid any scale deposits on the boiler. It should be noted that even a few millimetres of scale will greatly reduce the boiler's heat conductivity, causing a major drop in performance.


Treated water must be used in the heating circuit in the following cases:

- Very large circuits (containing a large amount of water).
- Frequent filling of the installation.


If it is necessary to drain partially or totally the water of the installation very often, we recommend filling it with treated water.

## 25 CHIMNEY SUPPORT

A chimney support is included in the documentation bag.



## 26 DIAGRAMS AND MEASUREMENTS



**IC:** Heating flow, 1" Female.

**IC':** Optional heating flow, 1" Female.


**RC:** Heating return, 1" Female.

**SH:** Fume outlet, Ø125 mm.

**V:** Drainage cock.

		Dimensions (mm)								
	IC/RC/IC'	A	B	C	D	E	F	G	H	I
BioClass NG 16	1" H	680	795	1055	940	180	235	850	745	335
BioClass NG 25		820	860	1135	1015	195	315	925	823	354

# BioClass NG (For external use)




	Hopper	
	P <sub>c</sub>	Size
BioClass NG 16	45 h	225 Kg
BioClass NG 25	37 h	

P<sub>c</sub>: Combustion period in hours at Q<sub>N</sub>.

## 27 ELECTRICAL CONNECTION DIAGRAM

### 27.1 Boiler



**L:** Phase.

**N:** Neutral.

**AX:** Feed auger.

**V:** Fan.

**LPH:** Heat exchanger cleaning device.

**Bbt:** BT buffer tank charging pump.

**BC:** Boiler pump.

**BA:** DHW tank pump or DHW valve.

**NO:** Multi-functional relay.

**NC:** Multi-functional relay.

**TA<sub>1</sub>:** Room thermostat.

**AL:** Hopper running out warning device.

**Dp:** Hopper level sensor.

**Sc:** Boiler temperature sensor.

**Ra/Sa:** DHW tank option resistance.

**Rbt/Sbt:** Resistance for BT tank Option.

**RT:** Remote relay.

**Sv:** Fan speed sensor.

**J1:** Power supply connector.

**J2:** Component connector.

**J3:** Component connector.

**J4:** Communication connector.

**J5:** **LAGO FB OT+** remote control connector.

**J6:** Room thermostat connector.


**J7:** Sensors connector.

**J8/J9:** Warning devices connector.

**J10:** Hopper level sensor connector.

# BioClass NG (For external use)

## 27.2 Burner



**Qout:** Burner outputs connector.

**R:** Ignition heater.

**LC:** Burner ash cleaning device.

**FC<sub>1</sub>:** Closed safety switch.

**FC<sub>2</sub>:** Opened safety switch.


**Qin:** Burner inputs connector.

**FC<sub>q</sub>:** Burner switch.

**FR:** Photocell.

**FC<sub>p</sub>:** Ash cleaning device switch.

## 27.3 Hopper




**J10:** Hopper level sensor connector.

**X3:** 3-way connector into the hopper.

**Dp:** Hopper level sensor.

# BioClass NG (For external use)

## 28 ELECTRICAL DIAGRAM



- TS:** Safety thermostat.
- TE:** Fuel entrance safety thermostat.
- Cv:** Fan capacitor.
- SPW:** Water pressure sensor.
- SPA:** Air pressure sensor.
- VAc:** Main power wiring.
- Qout:** Burner outputs connector.
- Qin:** Burner inputs connector.
- LCD:** Display communication connector.
- J4:** Communication connector.
- S1, S2:** Boiler model DIP-switch.

## 29 TECHNICAL DATA

MODEL		BioClass NG 16 OD	BioClass NG 25 OD
Maximum heat output	kW	15,6	25,3
Efficiency at maximum heat output	%	93,5	95
Minimum heat output	kW	4,2	6,9
Efficiency at minimum heat output	%	88,5	92
CO at maximum heat output (10% O <sub>2</sub> )	mg/m <sup>3</sup>	120	45
OGC (organic gaseous substances) at maximum heat output (10% O <sub>2</sub> )	mg/m <sup>3</sup>	6	<5
Particles content at maximum heat output (10% O <sub>2</sub> )	mg/m <sup>3</sup>	25	20
CO at minimum heat output (10% O <sub>2</sub> )	mg/m <sup>3</sup>	460	240
OGC (organic gaseous substances) at minimum heat output (10% O <sub>2</sub> )	mg/m <sup>3</sup>	20	5
Boiler class (according to EN 303-5)	-	Class 5	
Maximum operating pressure	bar	3	
Maximum operating temperature		80	
Maximum safety temperature	°C	110	
Water volume	l	55	73
Minimum flue draught	mbar	0,10	
Maximum flue draught	mbar	0,20	
Electrical supply	-	230 V~, 50 Hz, 1.5 A	
Boiler chimney diameter	mm	125	150
Fuel	-	6-8 mm wood pellet. Maximum length 35 mm.	
Maximum water content of the fuel	%	7	
Minimum return temperature	°C	25 °C	
Water pressure drop (dT = 20 K)	mbar	70	140
Stand by power	W	7	
Weight (net)	Kg	211	300

## 30 CIRCULATION PUMP AND PRESSURE DROP


**BioClass NG** is supplied with a circulation pump assembled inside the boiler. This pump is a high efficiency type circulation pump.

### 30.1 High efficiency circulation pump

The **high efficiency circulation pump** allows savings of up to 70 % in energetic consumption in comparison to conventional pumps. The pump can be adjusted in two ways:


#### 1-Constant speed I, II, III (traditional mode):

The pump operates at a constant, pre-set speed.




#### 2-Variable differential pressure ( $\Delta p-v$ ):

The setpoint value of the differential pressure H increases in a straight line between  $\frac{1}{2}H$  and H within the permitted flow margin. The differential pressure generated by the pump is adjusted to the appropriate setpoint value of differential pressure.



### 30.2 Boiler pressure drop

As well as the hydrodriving pressure of the pump, it is essential to consider the pressure drop of the installation to assure the correct sizing up of the hydraulic installation. The following diagram shows the pressure drop for **BioClass NG 16** boiler.



### 30.3 Circulating pump operating status


The high efficiency pump integrated within the boiler includes a Led (light), around the red knob, that displays their operating status. In the following table are described the status:

LED	DESCRIPTION	STATUS	CAUSE	SOLUTION
It lights green	The pump is functioning	The pump operates according to its setting	Normal functioning	
It flashes red/green	It is ready for service but it is not running	The pump will restart again automatically once the error has been solved	Low voltage: $U < 160\text{ V}$ Excess voltage: $U > 253\text{ V}$	Check the power supply: $195\text{ V} < U < 253\text{ V}$
			Excess of temperature of the pump: the temperature of the motor is too high	Check the room temperature and that of the fluid
Flashes red	The pump is out of order	The pump is stopped (blocked)	The pump does not restart automatically	Change the pump. Please contact your nearest official technical assistance service to have it replaced
Light off	There is no power supply	The pump is not receiving power supply	The pump is not connected to the power supply	Check the connection of the main power supply cable
			The LED is faulty	Check if the pump runs
			The pump is broken	Change the Pump. Please contact your nearest official technical assistance service to have it replaced

# BioClass NG (For external use)

## 31 SPARE PARTS LIST


### Boiler



<b>Nº.</b>	<b>Code</b>	<b>Name</b>	<b>Nº.</b>	<b>Code</b>	<b>Name</b>
1	SEPO002187	Left side panel NG 16	23	RALMBIO010	Supply Line NG 16
	SEPO002163	Left side panel NG 25		RALMBIO011	Supply Line NG
2	SEPO001981	Flue outlet cover NG 16	24	SEPO002018	Auger cover
	SEPO002165	Flue outlet cover NG 25	25	CFER000203	Auger cover seal
3	GCHABIO013	Heat exchanger NG 16	26	SELEBIO029	Main board NG 16
	GCHABIO014	Heat exchanger NG 25		SELEBIO022	Main board NG 25
4	CVAL000017	Safety valve	27	SEPO002071	Electrical connections cover NG 16
5	SEPO001977	Rear panel NG 16		SEPO002170	Electrical connections cover NG 25
	SEPO002162	Rear panel NG 25	28	SEPO002040	Air pressure sensor protection
6	CELC000252	Pressure transducer	29	SEPO002035	Air pressure sensor support
7	SCHA009633	Exhaust hole cover	30	CELC000331	Air pressure sensor
8	GLEVBIO009	Heat exchanger camshaft system NG 16	31	SEPO002186	Stiffness NG 16
	GLEVBIO010	Heat exchanger camshaft system NG 25		SEPO002167	Stiffness NG 25
9	SCHA009349	Deflector NG 16	32	CFER000202	Key
	SCHA009244	Deflector NG 25	33	CFER000199	Door lock
10	RBIO000019	Fan cover NG 16	34	CFER000200	Handle
	RBIO000020	Fan cover NG 25	35	SEPO001983	Door NG 16
11	MVAR240121	Butterfly screw		SEPO002160	Door NG 25
12	MAIS000139	Fan insulation	36	SCON000477	Ash drawer handle NG 16
13	CFOV000132	Fan		SCON000484	Ash drawer handle NG 25
14	CTOR000016	Fan screw	37	RCENBIO004	Ash drawer NG 16
15	SEPO002189	Top cover NG 16		RCENBIO005	Ash drawer NG 25
	SEPO002166	Top cover NG 25	38	MAIS000079	Glass braid
16	GFOV000002	Automatic air vent	39	RQUEBIO014	Burner NG 16
17	CFER000048	Spring		RQUEBIO011	Burner NG 25
18	COTR000010	Spy hole glass	40	SEPO002076	Ash drawer chute
19	CFOL000002	Spy hole nut	41	SEPO001957	Base NG 16
20	SCON000519	Internal supply Line NG 16		SEPO002154	Base NG 25
	SCON000529	Internal supply Line NG 25	42	CVAL000034	Drain tap
21	SEPO002188	Right side panel NG 16	43	CFOV000005	Expansion vessel 12 lts NG 16
	SEPO002164	Right side panel NG 25		CFOV000032	Expansion vessel 7,5 lts NG 25
22	CTOE000012	Pivot	44	CFOV000145	Pump




# Burner



## BioClass NG (For external use)

<u>Nº.</u>	<u>Código</u>	<u>Name</u>	<u>Nº.</u>	<u>Código</u>	<u>Name</u>
1	SEPO001900	Motor support cover	36	MVAR240228	M6x14 Allen screw
2	SCHA010252	Cleaner sensor support	37	SCON000621	Rear burner cover NG 16
3	CELC000352	Cap case		SCON000622	Rear burner cover NG 25
4	CELC000332	Cleaner sensor	38	MVAR240184	Rivet nut
5	SCHA010260	Cleaner sensor support	39	CELC000327	Burner position sensor.
6	SCON000834	Upper connecting rod NG 16	40	SCON000625	Burner body cover
	SCON000817	Upper connecting rod NG 25	41	MVAR240144	M4 hexagonal nut
7	MVAR240045	M6x20 screw	42	SCHA009624	Burner plate NG 16
8	SCON000730	Gear		SCHA009634	Burner plate NG 25
9	MVAR240039	M8X20 screw	43	MVAR240221	M4x35 Allen screw
10	SCON000816	Lower connecting rod	44	SCON000847	Crosshead NG 16
11	MVAR240043	M8 washer		SCON000841	Crosshead NG 25
12	MVAR240223	M8 Self locking nut	45	SCON000815	Shaft connecting rod sub-unit
13	MVAR240239	M6 washer	46	SCON000513	Upper wheel NG 16
14	MVAR240222	M6 Self locking nut		SCON000564	Upper wheel NG 25
15	CQUE000303	4-pole connector cover	47	CTOE000292	Wheel shaft
16	CQUE000135	7-pole connector	48	SCON000751	Burner cleaner sub-unit NG 16
17	CQUE000042	7-pole connector cover		SCON000749	Burner cleaner sub-unit NG 25
18	SEPO001764	Connectors support	49	MVAR240226	M5x35 Allen screw
19	CQUE000181	Photocell	50	SCON000833	Lower wheel NG 16
20	CFER000135	Cable duct		SCON000832	Lower wheel NG 25
21	CQUE000149	Photocell support	51	SCHA010330	Washer
22	SEPO001763	Burner cover	52	SCHA010366	Mixer washer
23	CRES000029	Electrical resistor	53	MVAR240222	M6 Self locking nut
24	SCHA009399	Photocell cover	54	CFER000189	Safety washer
25	CFER000188	Cable duct	55	MVAR240217	M6 washer
26	SEPO001899	Top cover	56	MVAR240240	Pin
27	MVAR240228	M6x14 screw	58	SCHA010525	1 mm key
28	CQUE000177	Lever	59	SCHA010512	2 mm key
29	SEPO001765	Air regulation cover NG 16			Whole Cleaning system NG 16 (12, 41, 42, 43, 44, 46, 47, 48, 49, 50, 51, 52, 53)
	SEPO001807	Air regulation cover NG 25	60	RBIO000000	
30	CFOV000135	20W motor transmisión 1/180			Whole Cleaning system NG 25 (12, 41, 42, 43, 44, 46, 47, 48, 49, 50, 51, 52, 53)
31	CFOV000141	YN 70 capacitor		RBIO000001	
32	SCON000825	Burner body NG 16			
	SCON000814	Burner body NG 25			
33	SCON000495	Combustion chamber sub-unit NG 16			
	SCON000558	Combustion chamber sub-unit NG 25			
34	MVAR240177	M6x16 screw			
35	SCHA009665	Photocell grid NG 16			
	SCHA009673	Photocell grid NG 25			


## Heat exchanger camshaft system



<b>N°.</b>	<b>Code</b>	<b>Name</b>	<b>N°.</b>	<b>Code</b>	<b>Name</b>
1	CTOE000241	Deflector coil NG 16	14	SCON000305	Outer plate sub-unit NG 16
	CTOE000242	Deflector coil NG 25		SCON000306	Outer plate sub-unit NG 25
2	MVAR240088	Flat washer	15	MVAR240209	Elastic pin
3	MVAR240168	Blade pin	16	MVAR240172	Allen stud
4	SCON000620	Cleaning plate sub-unit NG 16	17	SCON000307	Transmission crank sub-unit
	SCON000302	Cleaning plate sub-unit NG 25	18	CFOV000140	YN 60 capacitor
5	CTOE000289	Inner shaft NG 25	19	CFOV000134	10 W motor transmission 1/180
6	MVAR240189	Pin NG 25	20	SCON000758	Deflector tube sub-unit NG 16
7	SCON000303	Inner plate sub-unit NG 25		SCON000756	Deflector tube sub-unit NG 25
8	SCON000463	Inner plate sub-unit NG 16	21	SCON000752	Deflector tube support NG 16
9	MVAR240067	Hex head bolt		SCON000752	Deflector tube support NG 25
10	MVAR240103	Flat washer	22	SCHA011031	Subjection cleaning plate NG 16
11	CTOE000172	Cam system washer		SCHA010996	Subjection cleaning plate NG 25
12	CFER000129	Bearing			
13	MVAR240188	Self-locking hex nut			


## BioClass NG (For external use)

### Feed auger



<b>N°.</b>	<b>Code</b>	<b>Name</b>
1	CFOV000136	25W motor transmission 1/180
2	CFOV000142	YN 80 capacitor
3	SEPO002074	Fixing plate
4	SCON000863	Feed Screw NG 16
	SCON001162	Feed Screw NG 25
5	SEPO001975	Feed tube NG 16
	SEPO002156	Feed tube NG 25
6	CFER000019	Clamp
7	CFER000175	Polyurethane flex hose


## Electrical board



<b>N°.</b>	<b>Code</b>	<b>Name</b>	<b>N°.</b>	<b>Code</b>	<b>Name</b>
1	SEPO001994	Electrical board NG 16	7	SEPO002180	Drawer NG 16
	SEPO002159	Electrical board NG 25		SEPO002157	Drawer NG 25
2	COTR000063	Main board glass	8	CELC000022	Safety Thermostat 110 °C
3	SEPO001325	Panel fastening	9	CFOV000133	Fan motor capacitor
4	SCHA009564	Display fixing	10	SCHA009150	Ground plate
5	REBI336XXX	Display board	11	REBI335XXX	Power supply board
6	SEPO001993	Drawer cover NG 16	12	CELC000234	Boiler sensor
	SEPO002158	Drawer cover NG 25	13	REBI38XXX	Pellet sensor board

# BioClass NG (For external use)

## Wiring



N°.	Code	Description
1	CELC000343	Communication cable
2	CELC000347	Thermostat cable
3	CMAZ000123	Wiring harness
4	CELC000344	Burner output cable
5	CELC000349	Water pressure sensor cable
6	CELC000348	Burner input cable
7	CELC000345	Air pressure sensor cable
8	CMAZ000124	Pellets sensor board wiring

## 32 ALARM CODES

**BioClass NG** boiler is equipped with an electronic controller that performs continuous self-testing to detect any boiler malfunctioning. When it detects a functioning error, this is indicated by an alarm code on the display. The table below shows the list of the alarm codes:

CODE	ALARM	DESCRIPTION
E-01	Boiler temperature sensor open circuit, <b>S<sub>c</sub></b> .	The boiler sensor is damaged or disconnected. Contact your nearest official technical assistance service to have it replaced.
E-02	Boiler temperature sensor short-circuited, <b>S<sub>c</sub></b> .	
E-03	DHW temperature sensor open circuit, <b>S<sub>a</sub></b> .	The DHW sensor is damaged or disconnected. Contact your nearest official technical assistance service to have it replaced.
E-04	DHW temperature sensor short-circuited, <b>S<sub>a</sub></b> .	
E-05	Overheating in fuel entrance tube, <b>Te</b> .	The security thermostat of fuel entrance tube has exceeded the safety temperature of 80 °C. The boiler will lock out. To unlock the boiler wait the temperature drops, press the button on the safety thermostat and restore by pressing RESET button. If this alarm occurs repeatedly contact the nearest official technical assistance service.
E-06	Ignition failure.	Check the fuel content in the hopper or calibrate the feed auger. If this alarm occurs repeatedly contact the nearest official technical assistance service.
E-07	Burner ash cleaning system start step error.	These alarms occur when a bad running of the burner ash cleaning system is detected. If this alarm occurs repeatedly contact the nearest official technical assistance service.
E-08	Burner ash cleaning system final step error.	
E-09	Burner ash cleaning system switch error, <b>FCp</b> .	
E-10	Boiler water overheating.	The water in the boiler has exceeded the safety temperature of 100 °C. The boiler will lock out. The boiler will be unlocked automatically when the boiler temperature drops below 90 °C. If this alarm occurs repeatedly contact the nearest official technical assistance service.
E-11	Safety thermostat, <b>Ts</b> .	The water in the boiler has exceeded the safety temperature of 110 °C. The boiler will cut out. To unlock it, wait until the boiler drops below 100 °C and press the button on the safety thermostat. If this alarm occurs repeatedly contact the nearest official technical assistance service.
E-12	Burner switch, <b>FCq</b> .	Check if the burner is correctly fitted to the boiler. If this alarm occurs repeatedly contact the nearest official technical assistance service.
E-13	Insufficient air depression.	Check the correct running and connection of the air pressure sensor and that the burner and ashtray are correctly fitted to the boiler. If this alarm occurs repeatedly contact the nearest official technical assistance service.
E-14	Air depression fall down.	
E-15	Insufficient air depression during ignition pre-purge step.	
E-18	Water pressure sensor fault.	The water pressure sensor is damaged or disconnected. Contact your nearest official technical assistance service to have it replaced.

## BioClass NG (For external use)

CODE	ALARM	DESCRIPTION
E-19	Low water pressure.	The pressure of water in the installation drops below the minimum pressure set at P.19 parameter of the " <i>Technical Menu</i> " (by default 0,5 bar). The boiler will lock out. To unlock it, fill the installation again up to 1 - 1.5 bar. This alarm occurs when the water is drained from the installation, due to either leakage or maintenance operations. If this alarm occurs repeatedly contact the nearest official technical assistance service.
E-20	Safety valve fault.	When the installation pressure exceeds 3.5 bar, this alarm is displayed on the screen. The safety valve is damaged or it doesn't work properly. The boiler will lock out. The boiler will be unlocked, when the pressure drops below 2.5 bar again. Drain the installation up to 1 - 1.5 bar. Contact your nearest official technical assistance service to have it replaced.
E-21	Air pressure sensor fault.	The air pressure sensor is damaged or disconnected. Contact your nearest official technical assistance service to have it replaced.
E-22	Excessive air depression in the combustion chamber.	The air depression measured in the combustion chamber exceeds the limits of the air pressure sensor. The burner will be locked until the depression is correct again. If this alarm occurs repeatedly contact the nearest official technical assistance service.
E-23	Excessive air overpressure in the combustion chamber.	The air overpressure measured in the combustion chamber exceeds the limits of the air pressure sensor. The burner will be locked until the depression is correct again. If this alarm occurs repeatedly contact the nearest official technical assistance service.
E-25	Wrong calibration data.	The calibration data is wrong or it is set at OFF value. If this alarm occurs repeatedly contact the nearest official technical assistance service.
E-28	Overpressure of water.	When the boiler water pressure exceeds 2.5 bar, this alarm is displayed on the screen to warn of an excess of pressure in the installation. To restore the normal functioning of the boiler it is recommended to drain the installation again up to 1 - 1.5 bar. If this alarm occurs repeatedly contact the nearest official technical assistance service.
E-29	Fuel level sensor error.	Fuel level sensor is damaged or disconnected. Contact your nearest official technical assistance service to have it replaced.
E-30	Underfloor temperature sensor open circuit, <b>Sr1</b> .	Underfloor temperature sensor is damaged or disconnected. Contact your nearest official technical assistance service to have it replaced.
E-31	Underfloor temperature sensor short-circuited, <b>Sr1</b> .	
E-32	Underfloor temperature sensor open circuit, <b>Sr2</b> .	Underfloor temperature sensor is damaged or disconnected. Contact your nearest official technical assistance service to have it replaced.
E-33	Underfloor temperature sensor short-circuited, <b>Sr2</b> .	
E-34	Outdoor temperature sensor open circuit, <b>Sext</b> .	Outdoor temperature sensor is damaged or disconnected. Contact your nearest official technical assistance service to have it replaced.
E-35	Outdoor temperature sensor short-circuited, <b>Sext</b> .	

CODE	ALARM	DESCRIPTION
E-36	DIP-switch wrongly changed.	DIP-switch selector of the boiler is changed when the boiler is connected to the main supply. The boiler will be locked out until unplug and plug the boiler again.
E-37	Communication error with <b>BIO Hydraulic Kit</b> .	Communication failure between boiler and the <b>BIO Hydraulic Kit</b> . If this alarm occurs repeatedly contact the nearest official technical assistance service.
E-38	Lasting insufficient air depression during ignition pre-purge step.	Check the air pressure sensor and that the burner and ashtray are correctly fitted to the boiler. If this alarm occurs repeatedly contact the nearest official technical assistance service.
E-39	Insufficient fan speed.	Fan malfunction. If this alarm occurs repeatedly contact the nearest official technical assistance service.
E-40	Fan speed fall down.	
E-41	Lasting fan speed fall down.	
E-42	Communication error with <b>BIO Hydraulic Kit</b> .	Communication failure between boiler and the <b>BIO Hydraulic Kit</b> . If this alarm occurs repeatedly contact the nearest official technical assistance service.
E-43	Ashtray full.	Warning that the ashtray is full. The boiler will continue operate normally. To restore warning, the ashtray must be emptied and it is necessary to set the "Emptying ashes" parameter to 0 of the "User menu" (See "Ashtray status").
E-44	Boiler Maintenance.	Notice for maintenance of the boiler. Contact your nearest official technical assistance service to perform periodic maintenance of the boiler.
E-45	BT tank temperature sensor open circuit, <b>Sbt</b> .	BT tank temperature sensor is damaged or disconnected. Contact your nearest official technical assistance service to have it replaced.
E-46	BT tank temperature sensor shortcircuit, <b>Sbt</b> .	
E-47	Communication error with pellets level sensing unit.	Communication failure between boiler and the pellets sensing system board (PCB). If this alarm occurs repeatedly contact the nearest official technical assistance service.
E-48	Low fuel level in the hopper.	Warning that the hopper is going to run out of pellets (fuel reserve). The boiler will continue operate normally. Refill the hopper with pellets up to the sensor to restore the warning alarm.
E-49	Hopper is run out of fuel.	The hopper is completely empty of pellets. The boiler stops running to avoid emptying the auger. To restore boiler functioning refill the hopper with pellets up to the sensor and press RESET button.
E-50	Kit Aspiration NG and pellets sensing units connected together.	Kit Aspiration NG and pellets sensing units are connected together to boiler's main board. Contact your nearest official technical assistance service to disconnect one of the units.

### 33 GUARANTEE CONDITIONS

DOMUSA's commercial guarantee covers the standard functioning of the products manufactured by DOMUSA Calefacción S.Coop., in accordance with the following conditions and time periods:

1. This **commercial guarantee** is valid for the following periods, as from the **commissioning date**:

**2 Years** for electric and hydraulic elements: pumps, valves, etc.

**5 Years** for heat exchangers.

**5 Years** guarantee for outer panels against pitting corrosion.

**Exemptions:**

1. Panels are corroded due to accidental damage
2. Panels have been subject to corrosive liquids
3. Damage by large hail stones
4. Installation less than 100m from coast

During the 2-year period following the commissioning date, personnel authorized by Domusa will carry out any repairs of original flaws or defects totally free of charge.

After these 2 years have elapsed and until the end of the guarantee period, labour costs and call-out charges will be payable by the user.

2. The annual overhaul is not included in the terms of this guarantee.

3. The **commissioning** and **annual overhaul** are to be carried out by personnel authorised by Domusa.

4. The **commercial guarantee** will be null and void in the following cases:

- If the **annual overhaul** by personnel authorised by Domusa has not been carried out.
- If the boiler has not been installed in accordance with the applicable laws and regulations for this type of appliance.
- If the boiler has not been commissioned immediately after its installation, by personnel authorised by Domusa.

Failures due to misuse or incorrect installation, use of non-suitable power or fuel, supply with water with physical or chemical properties causing incrustation or corrosion, incorrect handling of the appliance and, in general, for any reason beyond Domusa's control, are excluded from this guarantee.

This guarantee does not affect the consumer's rights as stipulated by law.





**POSTAL ADDRESS**

Mail box No 95  
20730 AZPEITIA

Telfs: (+34) 943 813 899

**FACTORY AND OFFICES**

B° San Esteban s/n  
20737 ERREZIL (Gipuzkoa)

Fax: (+34) 943 815 666

**[www.domusa.es](http://www.domusa.es)**

DOMUSA reserves the right to make modifications of any kind to its product characteristics without prior notice.



CDOC001347

09/16